

SETTING UP A DIALOGUE BETWEEN THE XR25 AND THE COMPUTER

- Connect the test kit to the diagnostic socket.
- Ignition on.
- ISO selector on S8
- Type **D13**

9.INJ**COMPUTER IDENTIFICATION**

The computer is not identified by reading a fault code but by reading the Part Number directly from the computer. After having set up a dialogue with the computer:

ENTER G70***7700****XXX****XXX**

The Part Number will then appear on the central display in three sequences..


Each sequence is displayed for approximately two seconds. Each sequence is repeated twice. (To find the number, refer to the Workshop Repair Manual, section 12).

ERASING THE MEMORY (engine off, ignition on)

After the injection system has been worked on, the computer's memory can be erased by using the code G0** (Erasing memorised faults in diagnostic mode D13, ISO selector in position S8, enter G0**).

The memories of other components on the vehicle are not erased when this operation is used.

If information obtained from the XR25 means that electrical continuities have to be checked, connect the bornier **Sus. 1228**.



(The **Sus. 1228** consists of a 55 track base unit which has an integral printed circuit comprising 55 copper coated areas, numbered from 1 to 55).

Using the wiring diagrams, the tracks connecting the component or components can easily be checked.

IMPORTANT:

- All checks with the bornier **Sus. 1228** should only be performed with the battery disconnected.
- The bornier is designed to work with an ohmmeter only. Under no circumstances should a 12 volts supply be connected to the control points.

PRESENTATION OF FICHE N° 27 SIDE 1/2 WITH FAULT BARGRAPHS

N° 27 1/2		S8		code :	D	1	3	read :	G . n J
1	<input type="checkbox"/> ILLUMINATED → <input type="checkbox"/> EXTINGUISHED →	FAULT TEST TURN CARD		CODE PRESENT				<input type="checkbox"/>	
2	<input type="checkbox"/>	COMPUTER		ENGINE IMMOBILISER * 22				<input type="checkbox"/>	
3	<input type="checkbox"/>	AIR TEMPERATURE		O2 SENSOR * 23				<input type="checkbox"/>	
4	<input type="checkbox"/>	COOLANT TEMPERATURE		VEHICLE SPEED				<input type="checkbox"/>	
5	<input type="checkbox"/>	PRESSURE		FLYWHEEL SIGNAL * 25				<input type="checkbox"/>	
6	<input type="checkbox"/>	* 06 PINKING		THROTTLE POSITION				<input type="checkbox"/>	
7	<input type="checkbox"/>	CAMSHAFT		FUEL TANK PRESSURE				<input type="checkbox"/>	
8	<input type="checkbox"/>	* 08 FUEL PUMP		BLOCKING * 28				<input type="checkbox"/>	
9	<input type="checkbox"/>	* 09 ANTI - PERCOLATION		AIR PUMP * 29				<input type="checkbox"/>	
10	<input type="checkbox"/>	* 10 O2 SENSOR OVERHEATING		BI MODE * 30				<input type="checkbox"/>	

INJECTION (faults)

Memory del. : G 0 **

Status check request : G 0 1 *

11	<input type="checkbox"/> * 11	INJECTOR CIRCUIT	CONNECTION A.T. → INJ.	<input type="checkbox"/>
12	<input type="checkbox"/> * 12	WARN. LAMP CIRCUIT FAULT	DATA + FUEL PUMP	<input type="checkbox"/>
13	<input type="checkbox"/>	SAVE DATA IN MEMORY		
14	<input type="checkbox"/> * 14	IDLE SPEED REG. CIRCUIT	CANISTER PURGE CIRCUIT * 34	<input type="checkbox"/>
15	<input type="checkbox"/>	CONNECTION INJ. → A/C	EGR CIRCUIT * 35	<input type="checkbox"/>
16	<input type="checkbox"/> * 16	IGNITION COILS	COLD START INJECTORS * 36	<input type="checkbox"/>
17	<input type="checkbox"/> * 17	MIL WARNING LIGHT		
18				
19				
20	<input type="checkbox"/> * 20	COMPUTER CONFIGURATION	XR25 MEMORY 0	<input type="checkbox"/>

ADDITIONAL CHECKS : # ..

01	Pressure	mb
02	Coolant temp.	°C
03	Air temp.	°C
04	Computer feed	V
05	O2 sensor	V
06	Engine speed	rpm
12	Idling RCO	%
13	Pinking signal	
14	Speed difference	rpm
15	Pinking correct.	d°
16	Atmos. pressure	mb
17	Throttle pot.	
18	Vehicle speed	km per h
21	Auto. correct. of RCO idle speed	%
23	Canister purge RCO	%
24	RCO EGR	%
30	Auto. correct. of richness under high loads	
31	Auto. correct. of richness under low loads	
35	Mixture regulation	

END OF TEST: G 1 3 *

Part No. : G 7 0 *

Diagnostic faults :

Press V and 9

Return to diagnostic mode : D

15 ANG

PRESENTATION OF FICHE N° 27 SIDE 2/2 WITH STATUS BARGRAPHS

N° 27 2/2		read : 10.n J	
1	ILLUMINATED → STATUS TEST EXTINGUISHED → TURN CARD	CODE PRESENT	
2	Full Load ← THROTTLE POSITIONS → No load	CONTROL MODES : G 00 *	
3	FLYWHEEL SIGNAL	ACTIVE ENGINE IMMOBILISER	(If engine stationary)
4	PARK/NEUTRAL POSITION	+ APC COMPUTER	10 Fuel pump relay
5	TORQUE ADJUSTMENT	RELAY CONTROL LOCKING	11 Blocking relay
6	RICHNESS REGULATION	IDLING REGULATION	12 A/C compressor
7	FUEL PUMP CONTROL	CANISTER PURGE AUTHORIZED	14 Idle speed reg. valve
8	ANTI-PERCOLATION CONTROL	ELECT. WINDSCREEN CONTROL	16 Canister purge valve
9	SELECTION ACCELERATED IDLE SPEED		17 Anti percolation relay
10	REQUEST → AUTHORIZATION		21 Warning lamp fault
		22 Air pump relay	
		23 EGR valve	
		24 Bi-mode inlet valve	
		COMPUTER CONFIGURATION	
		(Vehicle with AT or MAN. GEARBOX)	
		See procedure in Workshop Manual	
(IMPORTANT : monitor bar graph 20 left)		ADDITIONAL CHECKS : # 00	
INJECTION (status)		01 Pressure mb	
Memory del. : G 00 **		02 Coolant temp. °C	
Request fault test : G 02 *		03 Air temp. °C	
11	SIGNAL CAMSHAFT	BLEED CANISTER + ACTIVE SOL. VALVES	04 Computer feed V
12	EGR SOLENOID CONTROL	ERASE MEMORISED FAULTS	05 02 sensor V
13	AIR PUMP CONTROL	POWER STEERING PRESSOSTAT	06 Engine speed rpm
14	BI-MODE INLET CONTROL	COLD START INJECTORS	12 Idling RCO %
15			13 Pinking signal
16			14 Speed difference rpm
17			15 Pinking correct. d°
18			16 Atmos. pressure mb
19	Veh. with AT COMPUTER CONFIGURATION Veh. with Man. gearbox		17 Throttle pot.
20	FAULT PRESENT	XR25 MEMORY	18 Vehicle speed km per h
		21 Auto. correct. of RCO idle % speed	
		23 Canister purge RCO %	
		24 RCO EGR %	
		30 Auto. correct. of richness under high loads	
		31 Auto. correct. of richness under low loads	
		35 Mixture regulation	
		END OF TEST : G 13 *	
		Part No. : G 70 *	
		Diagnosed faults :	
		Press V and 9	
		Return to diagnostic mode : D	
		15 ANG	


REPRESENTATION OF THE BARGRAPHS




Illuminates when a dialogue has been established with the product computer. If it remains extinguished:

- the code does not exist,
- there is a fault in the tool, the computer or the line.

REPRESENTATION OF THE FAULTS (always on a coloured background)



If illuminated, indicates a fault on the tested product, the associated text defines the fault.








If extinguished, indicates that the fault has not been found on the tested product.

REPRESENTATION OF THE STATUSES (always on a white background)


Engine off, ignition on, no operator action

The status bargraphs on the fiche are represented as the status which they should have when the engine is off, the ignition is on and there is no operator action

- If on the fiche the bargraph is represented as  the test kit should give as information 
- If on the fiche the bargraph is represented as  the test kit should give as information 
- If on the fiche the bargraph is represented as  the test kit should give as information

either  or 

Engine running



Extinguishes when the function or condition given on the fiche can no longer be performed.



Illuminates when the function or condition given on the fiche is performed.


FUNCTION V9

Fiche n° 27 side 1/2 and side 2/2 is a generic fiche used for several engines.

The different engines do not use all the bargraphs. To find out the bargraphs dealt with by the injection computer, after having set up a dialogue with the computer, press the V and 9 buttons simultaneously. The bargraphs dealt with will:

- illuminate permanently for non memorisable fault bargraphs or status bargraphs,
- flash for memorisable fault bargraphs.

To return to fault finding mode, press button D.

	<p>Bargraph 1 RH extinguished Fiche n° 27 side 1/2</p> <p><u>XR25 CIRCUIT</u></p> <p>XR25 assistance : no connection, CO, CC EARTH, CC + 12</p>
---	---

<p>NOTES</p>	<p>For fault finding, this bargraph should be illuminated</p>
---------------------	---

Check:

- all the injection fuses,
- the connection between the XR25 and the diagnostic socket,
- the position of the dial (S8),
- the conformity of the cassette.

Repair if necessary.

Check:

- the presence of + 12 V on track 16 and the earth on track 4 on the diagnostic socket.
- the connection between the XR25 and the diagnostic socket.

Diagnostic	15	→	4	XR25
socket	7	→	8	socket


Repair if necessary.

Connect the bornier **\$us. 1228** instead of the computer and check the insulation and continuity between the tracks:

Bornier	38	→	15	Diagnostic socket
	11	→	7	Diagnostic socket
	2	→	earth	Earth MH
	3	→	earth	Earth MH
	24	→	fuse	Engine – after ignition feed fuse
	28	→	3	Coil 1-4
	29	→	3	Coil 2-3
	54	→	2	Idle solenoid valve

Repair


<p>AFTER REPAIR</p>	<p>Carry out a conformity check</p>
----------------------------	-------------------------------------

<div>2</div> <div></div>	<div>Bargraph 2 LH illuminatedFiche n° 27 side 1/2</div> <div><u>COMPUTER CIRCUIT</u></div> <div>XR25 assistance: Computer fault if bargraph 2LH illuminated</div>
---	---

NOTES	None
--------------	------

<div>Computer is not correct or is faulty.</div> <div>Replace the injection computer.</div>


AFTER REPAIR	Carry out a conformity check
---------------------	------------------------------

<div data-bbox="353 243 382 277" data-label="Text">2</div> 	<div data-bbox="624 203 1166 251" data-label="Section-Header">Bargraph 2 RH illuminated</div> <div data-bbox="1683 209 2011 248" data-label="Text">Fiche n° 27 side 1/2</div> <div data-bbox="624 271 1242 313" data-label="Section-Header"><u>ENGINE IMMOBILISER CIRCUIT</u></div> <div data-bbox="618 328 1611 370" data-label="Text">XR25 assistance : CO or CC + 12 V line 35 of the computer</div>
--	--

<div data-bbox="294 571 443 613" data-label="Section-Header">NOTES</div>	None
---	------

<div data-bbox="200 794 1943 839" data-label="Text">Connect the bornier Sus. 1228 instead of the computer and check the insulation and continuity of line:</div> <div data-bbox="441 882 1212 927" data-label="Text"> <div data-bbox="441 882 628 921" data-label="Text">Bornier 35</div> <div data-bbox="685 899 838 930" data-label="Image"> </div> <div data-bbox="915 882 1212 921" data-label="Text">5 Decoder unit</div> </div> <div data-bbox="200 970 535 1015" data-label="Text">Repair if necessary.</div> <div data-bbox="200 1043 1122 1088" data-label="Text">If the fault persists, refer to status bargraph 3 RH side.</div>	
--	--


<div data-bbox="214 2635 515 2680" data-label="Section-Header">AFTER REPAIR</div>	Carry out a conformity check
--	------------------------------

<div style="text-align: center;">3</div> 	<div style="text-align: right;">Fiche n° 27 side 1/2</div> Bargraph 3 LH illuminated <u>AIR TEMPERATURE SENSOR CIRCUIT</u> XR25 assistance : #03 = -40 CO LINE 20 OR 46 ; CC — 5V LINE 20 #03 = 119 CC EARTH LINE 20 ; CC LINE 46/20
--	---

NOTES	If BG3RH ; BG4LH ; BG6RH ; BG12RH are illuminated, refer to BG6RH If BG6RH is illuminated, refer to BG6RH
--------------	--

Check the resistance of the air temperature sensor.	
If the resistance is not correct, replace the air temperature sensor and erase the computer memory using G0**.	
Connect the bornier Sus. 1228 instead of the computer and check the insulation and continuity of the electrical wiring between tracks: 1 sensor connector 46 bornier 2 sensor connector 20 bornier	
If the electrical wiring is correct, replace the computer.	


AFTER REPAIR	Carry out a conformity check
---------------------	------------------------------

<div style="text-align: center; margin-bottom: 10px;">3</div> 	<div style="text-align: right; margin-bottom: 10px;">Fiche n° 27 side 1/2</div> Bargraph 3 RH illuminated <u>OXYGEN SENSOR CIRCUIT</u> XR25 assistance : #35 = 128 CO LINE 17 or 18 ; CC - LINE 17 ; CC + 12V LINE 17 #05 > 1V CC + 12V LINE 17 ; #05 = 0.390 CO LINE 17 or 18 #05 = 0V CC EARTH LINE 17
---	--

NOTES	If BG3LH ; BG4LH ; BG6RH ; BG12RH are illuminated, refer to BG6RH
--------------	---

Check the connection and condition of the oxygen sensor connector.
Engine running, check for – 12V between tracks A and B on the oxygen sensor connector.
If there is not + 12V, repair the wiring for the sensor heating circuit.
Ignition off, connect bornier Sus. 1228 in place of the computer and check the continuity and insulation of the wiring between tracks : C/17 and C/18 (sensor connector /bornier)
If necessary, repair the wiring.
The fault persists ! Replace the oxygen sensor
The fault persists ! Replace the computer.


AFTER REPAIR	Carry out a conformity check
---------------------	------------------------------

<div style="text-align: center;">4</div> 	<div style="text-align: right;">Fiche n° 27 side 1/2</div> <p>Bargraph 4 LH illuminated</p> <p><u>COOLANT TEMPERATURE SENSOR CIRCUIT</u></p> <p>XR25 assistance: #02 = -40°C CC = 5V LINE 15 ; CO LINE 15 or 44 #02 = 119°C CC EARTH LINE 15 ; CC LINE 15/44 or 45/15</p>
--	--

NOTES	<p>If BG5LH is illuminated, refer to BG4RH</p> <p>If BG3LH ; BG3RH ; BG6RH ; BG12RH are illuminated, refer to BG6RH</p>
--------------	---

Check the resistance of the coolant temperature sensor.	
The resistance is not correct, replace the sensor.	
Connect the bornier Sus. 1228 instead of the computer and check the continuity and the insulation of the electrical wiring between the tracks:	
1 coolant temperature sensor	44 bornier
2 coolant temperature sensor	15 bornier
C pressure sensor	45 bornier
B throttle potentiometer	45 bornier
Repair if necessary.	
The fault persists! Replace the computer.	


AFTER REPAIR	Carry out a conformity check
---------------------	------------------------------

<p style="text-align: center;">4</p> 	<p style="text-align: right;">Fiche n° 27 side 1/2</p> <p>Bargraph 4 RH illuminated <u>VEHICLE SPEED SENSOR CIRCUIT</u></p> <p>XR25 assistance : CO or CC LINE 12</p>
--	--

NOTES	None
--------------	------

Carry out a road test and check the speed on the speedometer .
If the speed is zero, repair the wiring of track 12 of the computer and B of the sensor.
Check the connection and the feed of the speed sensor: + 12V on track A earth on track C
Repair if necessary.
The fault persists! Replace the speed sensor.

AFTER REPAIR	Erase the computer memory using G0** Carry out a road test Carry out a conformity check
---------------------	---

<div style="text-align: center;">5</div> 	<div style="text-align: right;">Fiche n° 27 side 1/2</div> Bargraph 5 LH illuminated <u>ABSOLUTE PRESSURE SENSOR CIRCUIT</u> XR25 assistance: #01 = 103 mb CO LINE 16 or LINE 44 or LINE 45; CC EARTH LINE 16 #01 = 928 mb CO LINE 44
--	--

NOTES	If BG4LH is illuminated, refer to BG4LH If BG6RH is illuminated, refer to BG6RH
--------------	--

Check the pressure sensor is electrically and pneumatically connected .
Ignition on, check that there is + 5V between track C and earth on track A.

There is not + 5V between track C and track A	
Connect the bornier Sus. 1228 instead of the computer and check the insulation and continuity between the tracks: A sensor connector 44 bornier C sensor connector 45 bornier	
Repair if necessary.	
There is not + 5V ! The fault persists! Replace the computer.	

There is + 5V between track C and track A	
Ignition on, check the return voltage (0.2 to 5 V) on track B of the sensor. Note: For this measurement, a vacuum pump can be used to check the voltage variation.	
If the voltage does not vary, replace the sensor.	

The voltage varies	
Connect the bornier Sus. 1228 instead of the computer and check the insulation and the continuity between track B of the sensor and 16 of the bornier.	
Repair if necessary.	
The fault persists! Replace the computer.	


AFTER REPAIR	Erase the computer memory using G0** Carry out a conformity check
---------------------	--

<div style="text-align: center; border-bottom: 1px solid black; margin-bottom: 5px;">5</div> <div style="border: 1px solid black; width: 40px; height: 20px; margin: 0 auto;"></div>	<div style="text-align: right; font-size: small;">Fiche n° 27 side 1/2</div> <p>Bargraph 5 RH illuminated</p> <p><u>FLYWHEEL SIGNAL CIRCUIT</u></p> <p>XR25 assistance : *25 = CO CO or CC EARTH LINE 33 or 34 *25 = CC.O INTERFERENCE *25 = In SENSOR WIRE INVERTED</p>
--	---

NOTES	None
--------------	------

Disconnect the sensor connector and check the resistance of the sensor between terminals A and B.
The resistance is not 200 ± 50 ohms. Replace the sensor.
The resistance is 200 ohms.
Connect the bornier Sus. 1228 instead of the computer and check the continuity and the insulation of the wiring between the tracks: <div><div>A sensor</div><div>34 bornier</div><div>B sensor</div><div>33 bornier</div></div>
Repair if necessary.
The fault persists! Replace the computer.


AFTER REPAIR	<p>Erase the computer memory using G0**</p> <p>Carry out a conformity check</p>
---------------------	---

<div style="text-align: center; margin-bottom: 10px;">6</div> 	<div style="text-align: right; font-size: small;">Fiche n° 27 side 1/2</div> <p>Bargraph 6 LH illuminated <u>PINKING SENSOR CIRCUIT</u></p> <p>XR25 assistance : #13 = 0 CC EARTH LINE 8 or CO LINE 8 and 44</p>
---	---

NOTES	None
--------------	------

Check the wiring of the faulty sensor.	
Repair if necessary.	
Connect the bornier Sus. 1228 instead of the computer and check the insulation and the continuity of the electrical wiring between the tracks: <div style="display: flex; justify-content: space-around; margin-top: 5px;"> 1 sensor 44 bornier 2 sensor 8 bornier </div>	
Repair if necessary.	
The fault persists! Replace the pinking sensor.	


AFTER REPAIR	Erase the computer memory using G0** Carry out a conformity check
---------------------	--

<div style="text-align: center; margin-bottom: 10px;">6</div> 	<div style="text-align: right;">Fiche n° 27 side 1/2</div> <p>Bargraph 6 RH illuminated</p> <p><u>THROTTLE POTENTIOMETER CIRCUIT</u></p> <p>XR25 assistance: #17 = 0 CO LINE 45 or 19 or CC EARTH LINE 19 or 45 #17 = 255 CO LINE 46 or CC LINE 19/45</p>
---	---

NOTES	<p>If BG3LH is illuminated, refer to BG6RH If BG20RH is illuminated, refer to BG6RH If BG5LH is illuminated, refer to BG6RH If BG3LH ; BG3RH ; BG4LH ; BG12RH are illuminated, refer to BG6RH</p>
--------------	---

Check the resistance of the throttle potentiometer between tracks A and B ($R > 4000$ ohms).							
Check the variation of the throttle potentiometer between tracks B and C.							
A-B < 4000 ohms or B-C does not vary. Replace the throttle potentiometer.							
A-B > 4000 ohms and B-C varies.							
<p>Connect the bornier Sus. 1228 instead of the computer and check the insulation and the continuity between tracks:</p> <table data-bbox="393 1258 982 1399"> <tr> <td>A potentiometer</td><td>46 bornier</td></tr> <tr> <td>B potentiometer</td><td>45 bornier</td></tr> <tr> <td>C potentiometer</td><td>19 bornier</td></tr> </table>		A potentiometer	46 bornier	B potentiometer	45 bornier	C potentiometer	19 bornier
A potentiometer	46 bornier						
B potentiometer	45 bornier						
C potentiometer	19 bornier						
Repair if necessary.							
The fault persists! Replace the computer.							

AFTER REPAIR	<p>Erase the computer memory using G0** Carry out a conformity check</p>
---------------------	--


<div style="text-align: center;">7</div> 	<div style="text-align: right;">Fiche n° 27 side 1/2</div> <p>Bargraph 7 LH illuminated</p> <p><u>CAMSHAFT SENSOR CIRCUIT</u></p> <p>XR25 assistance: CO or CC EARTH LINE 42 CC + 12V LINE 48 CC LINE 52/2</p>
--	---

NOTES	<p>If BG8LH is illuminated, refer to BG8LH</p> <p>If the vehicle does not start, refer to BG8LH</p>
--------------	---

<p>Engine running, check for the presence of 12V on terminal 3 of the sensor and the earth on terminal 1 of the sensor.</p>
<p>Repair if necessary.</p>
<p>Exit fault finding. Connect a cable to terminal Vin and enter G on the XR25.</p>
<p>Engine running, check for the presence of a frequency by connecting to terminal 2 of the camshaft sensor connector which is still connected.</p>
<p>Enter V on the XR25 to measure the voltage.</p>
<p>There is no frequency or voltage at terminal 2. Replace the sensor.</p>

<p>There is a frequency or voltage at terminal 2.</p>
<p>Connect the bornier Sus. 122B instead of the computer and check the continuity of line 42 bornier / 2 sensor and the insulation of this line from terminal 52 on the computer, earth and + 12 Volts.</p>
<p>Repair if necessary.</p>
<p>The fault persists! Replace the computer.</p>

AFTER REPAIR	<p>Erase the computer memory using G0**</p> <p>Carry out a conformity check</p>
---------------------	---

<div style="text-align: center;">8</div> 	<div style="text-align: right;">Fiche n° 27 side 1/2</div> <p>Bargraph 8 LH illuminated</p> <p><u>FUEL PUMP RELAY COMMAND CIRCUIT</u></p> <p>XR25 assistance:</p> <ul style="list-style-type: none"> *08 = CO.O CO or CC EARTH LINE 48 *08 = CC.1 CC + 12V LINE 48 *08 = Def MEMORISED FAULT
--	---

NOTES	If BG7LH is illuminated, refer to BG8LH
--------------	---

Check the impact sensor is correctly clipped in.

On the fuel pump relay, check for + 12V between tracks 1 and 2, during the **timed** phase when the ignition is turned on.

If there is – 12V between 1 and 2, replace the relay.

If there is not – 12V between 1 and 2, ignition on, check for + 12V on track 1 of the fuel pump relay.


If there is not + 12V on track 1, check the line of track 1 to the fuse.

If there is + 12V on track 1, connect **bornier Sus. 1228** instead of the computer and check the continuity and insulation between track 2 of the relay and track 48 of the bornier.

Repair if necessary.

The fault persists! Replace the injection computer.


AFTER REPAIR	<p>Erase the computer memory using G0**</p> <p>Carry out a conformity check</p>
---------------------	---

<div>11</div> 	<div>Bargraph 11 RH illuminated Fiche n° 27 side 1/2</div> <div><u>AUTOMATIC TRANSMISSION ---> INJECTION COMPUTER CONNECTION</u></div> <div>XR25 assistance: BG 11RH illuminated if there is a connection fault with the automatic transmission</div>
---	---

NOTES	Only if automatic transmission
--------------	--------------------------------

<p>Connect the bornier 5us. 1228 in place of the injection computer, and check the insulation and continuity of computer line 7 .</p> <p>Repair.</p>
<p>If the fault persists, refer to automatic transmission fault finding section.</p>

AFTER REPAIR	<p>Erase the computer memory using G0**</p> <p>Carry out a conformity check</p>
---------------------	---

<div style="text-align: center;">11</div> 	<div style="text-align: right;">Fiche n° 27 side 1/2</div> <p>Bargraph 11 LH illuminated</p> <p><u>INJECTION CIRCUIT</u></p> <p>XR25 assistance: *11 = X.CO.O CO or CC EARTH LINE 53 or 25 or 4 or 30 *11 = X.CC.1 CC + 12V LINE 53 or 25 or 4 or 30 *11 = Def MEMORISED FAULT</p>
---	--


NOTES	<p>X represents the cylinder N°.</p> <p>Starter motor operating, bargraph illuminates for 10 seconds.</p>
--------------	---

Check the resistance of each injector.

<p>The resistance is not correct Replace the faulty injector(s).</p>	
<p>The resistance is correct Connect the bornier Sus. 1228 instead of the computer and check the continuity and insulation between the injector connectors on track 2 and tracks 53, 25, 4 and 30.</p>	
<p>Repair the wiring if necessary.</p>	

The fault persists! Replace the computer.


AFTER REPAIR	<p>Erase the computer memory using G0** Carry out a conformity check</p>
---------------------	--

<div style="text-align: center;">12</div> 	<div style="text-align: right;">Fiche n° 27 side 1/2</div> <p>Bargraph 12 LH illuminated</p> <p><u>FAULT WARNING LIGHT CIRCUIT</u></p> <p>XR25 assistance: *12 = CO.O CO or CC EARTH LINE 26 *12 = CC.1 CC + 12V LINE 26</p>
---	---

NOTES	<p>BG12LH only illuminates when there is a fault on the warning light circuit and another fault simultaneously (<i>which normally illuminates the warning light</i>).</p>
--------------	---

Turn on the ignition and check that the fault warning light illuminates for 3 seconds.
If it does not illuminate, check the bulb.
Connect the bornier Sus. 1228 instead of the computer and check the insulation and continuity of line 26 / warning light bulb via R34.
Repair if necessary.
The fault persists! Replace the computer.

AFTER REPAIR	<p>Erase the computer memory using G0**</p> <p>Disconnect the pressure sensor and check the bargraphs with the XR25</p> <p>Erase the computer memory and carry out a conformity check</p>
---------------------	---

<div>12</div> 	<div>Bargraph 12 RH illuminated Fiche n° 27 side 1/2</div> <div><u>FUEL PUMP INFORMATION CIRCUIT</u></div> <div>XR25 assistance: CO LINE 52</div>
---	--

NOTES	If BG3LH ; BG3RH ; BG4LH ; BG6RH are illuminated, refer to BG6RH
--------------	--


Check for the presence of - 12V on track 3 of the fuel pump relay.
Repair if necessary.
During the timed phase when the ignition is turned on, check for the presence of + 12V on track 5 of the relay.

There is no - 12V on track 5 of the relay Replace the fuel pump relay.

There is + 12V on track 5 of the relay Connect the bornier Sus. 1228 instead of the computer and check the continuity between track 5 of the fuel pump relay and track 52 of the computer.
Repair if necessary.

The fault persists! Replace the computer.

AFTER REPAIR	Erase the computer memory using G0** Carry out a conformity check
---------------------	--

<div style="text-align: center;">14</div> 	<div style="text-align: right;">Fiche n° 27 side 1/2</div> Bargraph 14 LH illuminated <u>IDLE REGULATION VALVE CIRCUIT</u> XR25 assistance: <div style="display: flex; justify-content: space-between; margin-top: 5px;"> <div> *14 = CO.O *14 = CC.1 *14 = Def </div> <div> CO or CC EARTH LINE 54 CC + 12V LINE 54 MEMORISED FAULT </div> </div>
---	--

NOTES	With no fault, #12 should vary.
--------------	---------------------------------


Check the resistance of the winding between tracks 1 and 2 of the idle speed valve.
If the resistance is not correct, replace the idle speed regulation valve.
When the ignition is turned on, check during the timed phase for the presence of 12V on track 1 of the idle speed regulation valve.

There is not + 12V on track 1 Check the continuity between track 1 of the idle speed regulation valve connector and wire joint A1 in the engine wiring.
Repair if necessary.

There is + 12V on track 1 Connect the bornier Sus. 1228 instead of the computer. Check the insulation and the continuity of the wiring between track 2 of the idle speed regulation valve connector and track 54 of the bornier.
Repair if necessary.

The fault persists! Replace the computer.

AFTER REPAIR	Erase the computer memory using G0** Carry out a conformity check
---------------------	--

<div data-bbox="351 248 399 282" data-label="Text">14</div> 	<div data-bbox="620 206 1181 257" data-label="Text">Bargraph 14 RH illuminated</div> <div data-bbox="1675 212 2004 251" data-label="Text">Fiche n° 27 side 1/2</div> <div data-bbox="620 274 1133 319" data-label="Section-Header"><u>CANISTER BLEED CIRCUIT</u></div> <div data-bbox="620 333 1793 460" data-label="Text"> <p>XR25 assistance: *34 = CO.O CO or CC EARTH LINE 50 *34 = CC.1 CC + 12V LINE 50 *34 = Def MEMORISED FAULT</p> </div>
---	--

NOTES	#23 variable
--------------	--------------

Check the resistance of the canister bleed valve between tracks A and B.	
The resistance is not correct. Replace the canister bleed valve.	
The resistance is correct. Engine idling, check for the presence of + 12V on track A of the canister bleed valve.	
	There is not + 12V on track A Repair the wiring between track A of the canister bleed valve and wire joint A1 in the engine wiring.
	There is + 12V on track A Connect the bornier Sus. 1228 instead of the computer and check the insulation and the continuity of the electrical wiring between track B of the canister bleed valve and 50 of the bornier. Repair if necessary.
The fault persists! Replace the injection computer.	

AFTER REPAIR	Erase the computer memory using G0** Carry out a conformity check
---------------------	--

15

**Bargraph 15 LH illuminated**

Fiche n° 27 side 1/2

AIR CONDITIONING INJECTION CONNECTION CIRCUIT

XR25 assistance:

CC + 12 V of line 51 of the computer

NOTES

Check that the vehicle has air conditioning and if not, examine the other bargraphs

Connect the bornier **Sus. 1228** instead of the computer and check the insulation and continuity of line:


Bornier 51 \longrightarrow B5 Air conditioning control panel

Repair if necessary.

The fault persists, refer to checking the status bargraphs 9LH, 10LH, 10RH.

AFTER REPAIR

Carry out a conformity check

<div>16</div> 	<div>Bargraph 16 LH illuminated Fiche n° 27 side 1/2</div> <div><u>IGNITION COIL CIRCUIT</u></div> <div>XR25 assistance: *16 = 1.4 CC CO LINE 28</div> <div> *16 = 2.3 CC CO LINE 29</div>
---	--

NOTES	If there is CC EARTH, the fuse has blown and there is no dialogue with the XR25
--------------	---

Check the resistance of the faulty coil.

The resistance is not correct
Replace the faulty coil.

The resistance is correct
Connect the bornier Sus. 1228 instead of the computer and check the insulation and continuity of line 28/3 for coil 1 or 29/3 for coil 2 (bornier / coil).

Repair the faulty line.

The fault persists! Replace the computer.

AFTER REPAIR	Erase the computer memory using G0** Carry out a conformity check
---------------------	--

<div>2</div> <div><div></div><div></div></div>	<div>Bargraph 2 LH, 2 RH, incorrect illumination</div> <div>Fiche n° 27 side 2/2</div> <div><u>THROTTLE POSITION CIRCUIT</u></div> <div>XR25 assistance:</div> <div>BG 2LH illuminated if full load</div> <div>BG 2RH illuminated if no load</div> <div>BG 2LH and BG 2RH extinguished if middle position.</div>
--	--

NOTES	No fault bargraph should be illuminated
--------------	---

The fault is not electrical.


Check the mechanics of the accelerator circuit (cable, accelerator pedal, ...).

AFTER REPAIR	Carry out a conformity check
---------------------	------------------------------


<div>3</div> <div><div></div></div>	<div>Bargraph 3 LH, incorrect illumination</div> <div>Fiche n° 27 side 2/2</div> <div><u>FLYWHEEL SIGNAL CIRCUIT</u></div> <div>XR25 assistance: BG 3LH illuminated engine running</div>
-------------------------------------	--

<div>NOTES</div>	<div>Dealt with in the fault bargraphs.</div>
------------------	---

<div>AFTER REPAIR</div>	<div>None</div>
-------------------------	-----------------

<div data-bbox="334 251 355 285">3</div> 	<div data-bbox="600 208 1338 325">Bargraph 3 RH incorrect illumination <u>ENGINE IMMOBILISER CIRCUIT</u></div> <div data-bbox="1655 217 1983 259">Fiche n° 27 side 2/2</div> <div data-bbox="600 371 1878 414">XR25 assistance: BG 3LH illuminated, engine immobiliser active</div>
--	---

NOTES	Check the use of the correct PLIP if no fault bargraph is illuminated.
--------------	--


XR25 as a pulse detector,  and Vin.

Check for pulses on track 35 of the bornier when the PLIP is pressed



If pulses are noted, replace the injection computer.

If no pulses are noted, refer to the immobiliser fault finding section.

AFTER REPAIR	Carry out a conformity check
---------------------	------------------------------

<div style="text-align: center;">4</div> 	<div style="text-align: right;">Fiche n° 27 side 2/2</div> <p>Bargraph 4 LH incorrect illumination <u>PARK/NEUTRAL POSITION CIRCUIT</u></p> <p>XR25 assistance: Illuminated if Park/Neutral position</p>
--	---

NOTES	Only with automatic transmission
--------------	----------------------------------


<p>XR25 on voltmeter  and Vin.</p> <p>Connect a wire to Vin and track 7 of the injection computer.</p> <p>Ignition on, engage and release the gear lever in the P/N position, the voltage should change from 0 V to 5 V.</p>	
If correct, replace the injection computer.	
<p>If there is not 0 V / 5 V, check the insulation and continuity of the line:</p> <p style="text-align: center;">Injection computer 7  35 Automatic transmission computer</p> <p>Repair if necessary.</p>	
The fault persists! Refer to the automatic transmission fault finding section	

AFTER REPAIR	Carry out a conformity check
---------------------	------------------------------

<div>4</div> <div><div></div><div></div></div>	<div>Bargraph 4 RH incorrect illumination<div>Fiche n° 27 side 2/2</div></div> <div><u>+ AFTER IGNITION CIRCUIT</u></div> <div>XR25 assistance: BG 4RH illuminated if + after ignition</div>
--	--

NOTES	Dealt with in the fault bargraphs.
--------------	------------------------------------


AFTER REPAIR	None
---------------------	------

<div>5</div> 	<div>Bargraph 5 LH incorrect illumination</div> <div>Fiche n° 27 side 2/2</div> <div><u>TORQUE REDUCTION CIRCUIT</u></div> <div>XR25 assistance: Illuminated every time a gear is changed with automatic transmission</div>
--	--


NOTES	Only with automatic transmission Status bargraph 4 LH is correctly illuminated.
--------------	--

Since status bargraph 4 LH is correctly illuminated, the injection computer is not faulty.
Refer to the automatic transmission fault finding section


AFTER REPAIR	Carry out automatic transmission fault finding if status bargraph 4 LH is correctly illuminated
---------------------	---

<div style="text-align: center;">6</div> 	<div style="text-align: right;">Fiche n° 27 side 2/2</div> <p>Bargraph 6 LH incorrect illumination</p> <p><u>RICHNESS REGULATION CIRCUIT</u></p> <p>XR25 assistance: BG 6LH illuminated when the richness is regulated (Engine running)</p>
--	--


NOTES	Dealt with in the fault bargraphs.
--------------	------------------------------------

<div style="text-align: center;">6</div> 	<div style="text-align: right;">Fiche n° 27 side 2/2</div> <p>Bargraph 6 RH incorrect illumination</p> <p><u>IDLE REGULATION CIRCUIT</u></p> <p>XR25 assistance: BG 6RH illuminated engine running</p>
---	---

NOTES	Dealt with in the fault bargraphs.
--------------	------------------------------------

<div style="text-align: center;">7</div> 	<div style="text-align: right;">Fiche n° 27 side 2/2</div> <p>Bargraph 7 LH incorrect illumination</p> <p><u>FUEL PUMP COMMAND CIRCUIT</u></p> <p>XR25 assistance: BG 7LH illuminated ignition on</p>
--	--

NOTES	Dealt with in the fault bargraphs.
--------------	------------------------------------

<div style="text-align: center;">7</div> 	<div style="text-align: right;">Fiche n° 27 side 2/2</div> <p>Bargraph 7 RH incorrect illumination</p> <p><u>CANISTER BLEED CIRCUIT</u></p> <p>XR25 assistance: BG 7RH illuminated when canister bleed authorised.</p>
--	---

NOTES	Dealt with in the fault bargraphs.
--------------	------------------------------------

AFTER REPAIR	None
---------------------	------

<div data-bbox="351 243 373 271">8</div> <div data-bbox="187 299 548 412"></div>	<div data-bbox="618 200 1428 313">Bargraph 8 LH incorrect illumination <u>ANTIPERCOLATION COMMAND CIRCUIT</u></div> <div data-bbox="1675 209 2000 246">Fiche n° 27 side 2/2</div> <div data-bbox="618 361 1924 404">XR25 assistance: BG 8LH illuminated when antipercolation active</div>
---	---

NOTES	Dealt with in the fault bargraphs.
--------------	------------------------------------


AFTER REPAIR	None
---------------------	------

<div style="text-align: center;">9</div> <div style="border: 1px solid black; width: 50px; height: 30px; margin: 0 auto;"></div> <div style="text-align: center;">10</div> <div style="display: flex; justify-content: space-around; margin-top: 10px;"> <div style="border: 1px solid black; width: 50px; height: 30px;"></div> <div style="border: 1px solid black; width: 50px; height: 30px;"></div> </div>	Bargraphs 9LH, 10LH, 10RH incorrect illumination Fiche n° 27 side 2/2 <u>AIR CONDITIONING CIRCUIT</u> XR25 assistance: 9LH illuminated if air conditioning selected 10LH illuminated if air conditioning requested 10RH illuminated if air conditioning authorised
---	---

NOTES	All fault bargraphs must be dealt with, air conditioning must be fitted on the vehicle and selected
--------------	---

Connect the bornier Sus. 1228 instead of the computer and check the insulation and the continuity between track: <div style="display: flex; align-items: center; margin-top: 10px;"> <div style="margin-right: 20px;">Injection computer</div> <div style="margin-right: 20px;"> 6 \longrightarrow B4 51 \longrightarrow B5 </div> <div>Air conditioning control panel</div> </div> Repair if necessary.	
XR25 on voltmeter V , check on track 6 of the bornier for the presence of 12 V. There is not 12 V, refer to the air conditioning fault finding section.	
XR25 on voltmeter V injection computer connected, check for the presence of 12 V on track 85 of the air conditioning control panel. There is not 12 V, replace the injection computer. There is 12 V, refer to the air conditioning fault finding section.	

AFTER REPAIR	Carry out a conformity check
---------------------	------------------------------

<div>11</div> <div></div>	<div>Bargraph 11 LH incorrect illuminationFiche n° 27 side 2/2</div> <div><u>CAMSHAFT SIGNAL CIRCUIT</u></div> <div>XR25 assistance:BG 11LH illuminated engine running</div>
--	--

NOTES	Dealt with in the fault bargraphs.
--------------	------------------------------------

AFTER REPAIR	None
---------------------	------

NOTES

Only refer to these customer complaints after having performed a complete test using the XR25.

STARTING PROBLEMS

Does not start

Chart 1

Starts but stalls

Chart 2

Starting is too long

Chart 3

IDLE PROBLEMS

Too fast

Chart 4

Too slow

Chart 5

Engine unstable

Chart 6

Hunting

Chart 7

BEHAVIOUR WHEN DRIVING

Lacks performance

Chart 8

Misfiring and hesitation

Chart 9

SMOKE - POLLUTION

Gas analysis not correct

Chart 10

Testing the oxygen sensor

Chart 11

HIGH PETROL CONSUMPTION

Chart 12


ENGINE NOISE

Pinking


Chart 13

Chart 1**STARTING PROBLEMS**
Does not start**NOTES**

Only refer to this customer complaint after having performed a complete test using the XR25.

**AFTER REPAIR**

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check


Chart 1
CONT**AFTER REPAIR**

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 1A

STARTING PROBLEMS
Does not start**NOTES**

Only refer to this customer complaint after having performed a complete test using the XR25.

**AFTER REPAIR**

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 2**STARTING PROBLEMS**
The engine starts but stalls**NOTES**

Only refer to this customer complaint after having performed a complete test using the XR25.

Ignition on,
on the XR25, check the value of
#12 and 21.
Are these values coherent?

no

Refer to bargraph 14 LH fault chart.

yes

Check the air inlet circuit and the exhaust
pipe.
Repair if necessary.
If the fault persists

Check the fuel flow and pressure.
Repair if necessary [pump, filter, regulator,
pipes, injectors (seals) ...]
If the fault persists

There is a problem with the engine
and the injection is not faulty.

AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 3

STARTING PROBLEMS
Starting is too long**NOTES**

Only refer to this customer complaint after having performed a complete test using the XR25.

Connect the OPTIMA 5800 diagnostic station and perform a starting test. Does the station detect a fault?

yes

Follow the instructions.

no

Perform a test on the station with the engine running.
Does the station detect a fault?

yes

Follow the instructions.

no

Check the fuel flow and pressure
(Refer to vehicle Workshop Repair Manual.
Repair the fuel circuit if necessary (pump,
filter, pipes, regulator, injectors...)).
If the fault persists

Check the injectors are correctly sealed.
If they are not correctly sealed,
replace the faulty injector or injectors.
If the fault persists

There is a problem with the engine and the
injection is not faulty.

AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 4

IDLE PROBLEMS
Idle too fast**NOTES**

Only refer to this customer complaint after having performed a complete test using the XR25..

R > theoretical idle speed or #12 < theoretical value
especially power assisted steering pressostat, #02 (coolant temperature)

Check no air is leaking into the manifold
(seals, take-off points on the inlet manifold,
plugs, ...).
Repair if necessary.
If the fault persists

Check on the throttle body that it is up
against the lower mechanical stop (#17 <
theoretical value). Also check the accelerator
control. Repair if necessary.
If the fault persists

Check the fuel pressure is not too high.
Repair if necessary
(injectors, pump, pressure regulation,
pipes, ...).
If the fault persists

The injection is not faulty.
Check the engine.

AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 5

IDLE PROBLEMS
Idle too slow

NOTES

Only refer to this customer complaint after having performed a complete test using the XR25.
 $R < \text{theoretical idle speed}$ or $\#12 > \text{theoretical value}$

Connect the OPTIMA 5800 diagnostic station and perform an ignition test with the engine running.
Does the station detect a fault?

yes

Follow the instructions.

no

Check the fuel flow and pressure (refer to vehicle Workshop Repair Manual).
Repair the fuel circuit if necessary (pump, filter, pipes, regulator, injectors, ...).
If the fault persists

The injection is not faulty.
Check the engine.

AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 6**IDLE PROBLEMS**
Engine unstable**NOTES**

Only refer to this customer complaint after having performed a complete test using the XR25.

Perform a gas analysis
(Refer to fault chart 10 - smoke/pollution).
If the fault persists

Connect the OPTIMA 5800 diagnostic station
and perform an ignition test with the engine
running.
Does the station detect a fault?

yes

Follow the instructions.

no

Check the operation of the oxygen sensor
(Refer to fault chart 11 - smoke/pollution).
If the fault persists

Engine idling, check the coherence of #01
(the value read should be less than 500 mbar).
Is it correct?

no

Check the absolute pressure sensor and its
wiring loom. Repair,
and if necessary replace the sensor.

yes

Check the fuel flow and pressure
(refer to vehicle Workshop Repair Manual).
Repair the fuel circuit if necessary (pump,
filter, pipes, regulator, injectors, ...).
If the fault persists

A

AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 6
CONT**A**

Check the seal and the flow of the injectors.
Repair if necessary.
If the fault persists

Check the general condition of the engine
using engine compression tests with the
OPTIMA 5800 station.

AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 7

IDLE PROBLEMS
Hunting**NOTES**

Only refer to this customer complaint after having performed a complete test using the XR25.

Perform a gas analysis
(Refer to fault chart 10 - smoke/pollution)
If the fault persists

Connect the OPTIMA 5800 diagnostic station
and perform an ignition test with the engine
running.
Does the station detect a fault?

yes

Follow the instructions.

no

Check the operation of the oxygen sensor
(Refer to fault chart 11 - Smoke/pollution).
If the fault persists

Check there is no air leak on the inlet
manifold and check the operation of the
injectors (seizing...).

AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 8**BEHAVIOUR WHEN DRIVING**
Lacks performance**NOTES**

Only refer to this customer complaint after having performed a complete test using the XR25.

Check the throttle opens fully
(full load bargraph illuminated).
Check the adjustment of the accelerator
control. Repair if necessary.
If the fault persists

Check the air filter: dirty, deformed. Repair if
necessary.
If the fault persists

Connect the OPTIMA 5800 diagnostic station
and perform an ignition test with the engine
running.
Does the station detect a fault?

yes

Follow the instructions.

no

Perform a gas analysis
(Refer to fault chart 10 - Smoke/pollution).
If the fault persists

Connect the OPTIMA 5800 diagnostic station
and perform an engine compression test
Is it normal?

no


There is a problem with the engine.

yes

A

AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 8
CONT**AFTER REPAIR**

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 9**BEHAVIOUR WHEN DRIVING**
Misfiring and hesitation**NOTES**

Only refer to this customer complaint after having performed a complete test using the XR25.

Perform a road test if possible to highlight the fault.
If the fault is reproduced

Connect the OPTIMA 5800 diagnostic station and perform an ignition test with the engine running.
Does the station detect a fault?

yes

Follow the instructions.

no

Perform a gas analysis
(Refer to fault chart 10 - Smoke/pollution).
If the fault persists

Check the oxygen sensor
(Refer to fault chart 1.1 - Smoke/pollution).
If the fault persists

Check for the presence and the cleanliness of the restriction in the absolute pressure sensor pipe.
Repair if necessary.
If the fault persists

Check the seal of the injectors, and the fuel flow and pressure (refer to Workshop Repair Manual). Repair if necessary.
If the fault persists

A

AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 9
CONT**A**

Check the condition of the flywheel target.
This is done by using the engine speed sensor
signal display function on the OPTIMA 5800
station.
Repair if necessary.
If the fault persists

Check the valves are not clogged.
Clean the valves if necessary.
After cleaning, does the fault persist?

yes

There is a problem with the engine,
the injection is not faulty.

AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 10

SMOKE - POLLUTION
Gas analysis not correct
NOTES

Only refer to this customer complaint after having performed a complete test using the XR25.

Connect the OPTIMA 5800 diagnostic station and connect it to a 4040, 5040 or AGM 1500 type 4 gas analyser. Perform an anti-pollution/ gas analysis test. Does the station detect a fault?

no

End of fault finding using fault chart 10
 NOTE: a correct gas analysis indicates that the catalytic converter is working correctly.

yes

Is the CO too high (CO > 0.5 when idling or CO > 0.3 at 2500 rpm.) ?

yes

Check the oxygen sensor
 (Refer to fault chart 11 - Smoke/pollution).
 If the fault persists.

no


Check there is not a problem with the engine
 by performing a compression test
 (OPTIMA 5800 diagnostic station).

Check the catalytic converter (efficient, fusion, presence of lead, ...), the air supply (filter, manifold, ...), and the condition of the engine (abnormal oil consumption).

A


AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
 Erase the computer memory using G0**
 Carry out a conformity check

Chart 10
CONT 1**AFTER REPAIR**


Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 10 CONT 2



AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 10
CONT 3**AFTER REPAIR**

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 11**SMOKE - POLLUTION**
Testing the oxygen sensor**NOTES**

Only refer to this customer complaint after having performed a complete test using the XR25, especially the following parameters:

- #35 (richness correction): this should oscillate around 128
- #30 and #31 (adaptive richness): under no circumstances should they be at their limits.

Connect the OPTIMA 5800 diagnostic station and perform an anti-pollution / oxygen sensor test.
Does the station detect a fault?

no

End of fault finding using fault chart 11.
The oxygen sensor is not faulty.

yes

Check the sensor heating:
- presence of + 12 V at the connector with the engine running,
- the sensor heating resistor is not in an open circuit or short circuited to earth.
If the heating is correct

Is the minimum voltage too high?
($U_{min} > 300 \text{ mV}$: signal offset towards richness).

yes

Connect the OPTIMA 5800 diagnostic station and perform an ignition test with the engine running.
If the station does not detect a fault

no

Check the fuel pressure (regulator), the injectors (seal,...) the anti-evaporation circuit (canister) and the fuel grade.
Repair if necessary.
If the fault persists

Replace the sensor.


A

AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check


Chart 11

CONT 1



AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 11
CONT 2**AFTER REPAIR**

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 12

HIGH FUEL CONSUMPTION

NOTES

Only refer to this customer complaint after having performed a complete test using the XR25.

Check there are no fuel leaks.
Repair if necessary.
If the fault persists

Check the idle speed
(#06 on XR25).
Is it correct?

no

Refer to fault chart 4 or 5, idle problems
(idle speed too fast or too slow).

yes

Check the vehicle complies with its definition
and is in good condition.
Repair if necessary.
If the fault persists

Perform a gas analysis
(Refer to fault chart 10 - Smoke/pollution).
If the fault persists

Check the operation of the O₂ sensor
(Refer to fault chart 11 - Smoke/pollution).
If the fault persists

A

AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 12 CONT

A

Connect the OPTIMA 5800 diagnostic station
and perform an engine compression test.
Is it normal?

no

There is a **problem** with the engine.

yes

Check the petrol flow and pressure
(methods, refer to vehicle Workshop Repair
Manual) and the canister bleed circuit.
Repair if necessary
(regulator, pump, filter, pipes).
Does the fault persist?

yes

This is not an injection problem, there is a
problem with the engine.
Check:

- engine oil level
- coolant
- axle assemblies
- the general condition of the engine.

If necessary, perform a consumption test with
the ECONOTEST consumption device.


AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check


Chart 13

ENGINE NOISE
Pinking**NOTES**

Only refer to this customer complaint after having performed a complete test using the XR25.

**AFTER REPAIR**

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 13
CONT**AFTER REPAIR**

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

NOTES

Only refer to these customer complaints after having performed a complete test using the XR25

STARTING PROBLEMS

Does not start

Chart 1

Starts but stalls

Chart 2

Starting is too long

Chart 3

IDLE PROBLEMS

Too fast

Chart 4

Too slow

Chart 5

Engine unstable

Chart 6

Hunting

Chart 7

BEHAVIOUR WHEN DRIVING

Lacks performance

Chart 8

Misfiring and hesitation

Chart 9

SMOKE - POLLUTION

CO and/or HC too high

Chart 10

HIGH PETROL CONSUMPTION

Chart 11

ENGINE NOISE

Pinking

Chart 12



The method without the OPTIMA station does not comply with a sufficient quality criterion. Use the method with the OPTIMA station to obtain this quality criterion.

Chart 1

STARTING PROBLEMS
Does not start**NOTES**

Only refer to this customer complaint after having performed a complete test using the XR25

Check the impact sensor is correctly engaged.
Check fuses F12, F30, F60 :

F31 = 15 A	} On passenger compartment connection unit
F41 = 5 A	
30 A fuse	On engine compartment connection unit

Repair if necessary.
Does the fault persist?

no

End of fault finding

yes

Does the fuel pump make a noise when the ignition is turned on?

yes

See Chart 1A

no

Perform control mode G10*
and check if the relay makes a noise
(several clicking noises). Is it correct?

no

Replace the relay.

yes

Check for the presence of 12 V on track 3
of this relay.
Repair if necessary.
If the fault persists

During the timed phase, check for the
presence of 12 V on track 5 of this relay.
Is it correct?

no


Replace the relay.

yes

A

AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 1
CONT**AFTER REPAIR**


Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 1A

STARTING PROBLEMS
Does not start


NOTES

Only refer to this customer complaint after having performed a complete test using the XR25.



AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 1A
CONT**AFTER REPAIR**

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using GO**
Carry out a conformity check

Chart 2**STARTING PROBLEMS**
The engine starts but stalls**NOTES**

Only refer to this customer complaint after having performed a complete test using the XR25

Ignition on,
check on the XR25
the value on #12.
Is it between 93 and 97 %?

no

Refer to bargraph 14 LH fault chart.

yes

Check the air inlet circuit and the exhaust
pipe.
Repair if necessary.
If the fault persists

Check the petrol flow and pressure.
Repair if necessary [pump, filter, regulator,
pipes, injectors (sealing) ...]
If the fault persists

This is an engine problem
and the injection is not faulty.


AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 3

STARTING PROBLEMS
Starting is too long**NOTES**

Only refer to this customer complaint after having performed a complete test using the XR25

**AFTER REPAIR**

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 4

IDLE PROBLEMS

Idle too fast

NOTES

Only refer to this customer complaint after having performed a complete test using the XR25.

R > 750 rpm or #12 < 27 %

Check there is no air leak on the inlet (seals, take-off points on the inlet manifold, plugs, ...).
Repair if necessary.
If the fault persists

Check on the throttle body that it is up against the lower mechanical stop (#17 < 47). Also check the accelerator control.
Repair if necessary.
If the fault persists

Check the fuel pressure is not too high.
Repair if necessary
(injectors, pump, pressure regulator, pipes, ...).
The fault persists!

The injection is not faulty.
Check the engine.


AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 5

IDLE PROBLEMS
Idle too slow**NOTES**

Only refer to this customer complaint after having performed a complete test using the XR25
R < 650 rpm or #12 > 37 %

**AFTER REPAIR**


Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 6

IDLE PROBLEMS
Engine unstable


NOTES

Only refer to this customer complaint after having performed a complete test using the XR25



AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 6
CONT**AFTER REPAIR**

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 7

IDLE PROBLEMS
Hunting**NOTES**

Only refer to this customer complaint after having performed a complete test using the XR25

With the XR25 check if
no load bargraph (2 RH) is illuminated.
Is it illuminated?

no

If no load bargraph is extinguished or flashing but does not illuminate bargraph 6 RH, there may be a short circuit to + 5 V on line 46 of the computer (#17 = variable).
Check the insulation of the wiring and repair.

yes

Check the value of the pollutants and
Lambda.

- CO < 0.3 %
 - HC ≤ 100 ppm
 - CO₂ ≥ 14.5 %
 - 0.97 ≤ Lambda ≤ 1.03
- Is it correct?

no

- Check:
- the catalytic converter (melted, blocked, ...).
 - the oxygen sensor (polluted, heating faulty, ...).
 - air leak upstream of the oxygen sensor.
 - the seal of the exhaust pipe.
 - the type of fuel used.
 - the ignition (spark plugs, high voltage leads, coils).
 - the general condition of the engine (timing, ...).

yes

Disconnect the oxygen sensor and wait for
#35 to stabilise at 128 and #05 = 0.402, and
for bargraph 3 RH to illuminate.
Is the engine stable?

no

Check there is no air leak on the inlet
manifold (plugs, seals, take-off points,...)
Repair if necessary.

yes

Replace the oxygen sensor.

AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 8

BEHAVIOUR WHEN DRIVING
Lacks performance

NOTES

Only refer to this customer complaint after having performed a complete test using the XR25

Check the throttle opens fully
(full load bargraph illuminated).
Check the adjustment of the accelerator
control.
Repair if necessary.
Does the fault persist?

no

End of fault finding.

yes

Check the conformity of the spark plugs and
their condition.
Repair if necessary.
Does the fault persist?

no

End of fault finding.

yes

Check the values of the pollutants and
Lambda.
- CO < 0.3 %
- HC ≤ 100 ppm
- CO₂ ≥ 14.5 %
- 0.97 ≤ Lambda ≤ 1.03
Is it correct?

no

Check:

- the catalytic converter (melted, blocked, ...).
- the oxygen sensor (polluted, heating faulty, ...).
- air leak upstream of the oxygen sensor.
- the seal of the exhaust pipe.
- the type of fuel used.
- the ignition (spark plugs, high voltage leads, coils).
- the general condition of the engine (timing, ...).

yes

Check the air inlet circuit (air filter,...) and the
exhaust pipe.
Repair if necessary.
Does the fault persist?

no


End of fault finding.

yes

A

AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check


Chart 8
CONT**AFTER REPAIR**

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check


Chart 9

BEHAVIOUR WHEN DRIVING
Misfiring and hesitation**NOTES**

Only refer to this customer complaint after having performed a complete test using the XR25

**AFTER REPAIR**

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using GD**
Carry out a conformity check

**AFTER REPAIR**

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 10

SMOKE - POLLUTION
CO and/or HC too high

NOTES

Only refer to this customer complaint after having performed a complete test using the XR25. CO and / or HC too high
CO > 0.3 % - HC > 100 ppm

With the XR25, check on #05, 35.
Checking, refer to Workshop Repair Manual.
Is it correct?

no

yes

Check the high voltage circuit,
(spark plugs, spark plug leads).
Repair if necessary.
If the fault persists

Check the air supply,
the air filter, the pipes ...
After repairing,
does the fault persist?

no

yes

Check the conformity of the restriction and
the condition of the pipe for the absolute
pressure sensor.
Repair if necessary.
If the fault persists

Check the seal of the injectors.
(especially the O-rings).
Repair if necessary.
Does the fault persist?

no

yes

A

Test for the presence of lead
(refer to Workshop Repair Manual).
Is there lead?

yes

no

B

Check the type of fuel used.
If the customer has used leaded petrol and
before changing the catalytic converter and
the oxygen sensor, drive the vehicle using
several tanks of unleaded petrol.


End of fault finding.

End of fault finding.

AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 10 CONT



AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 11

HIGH PETROL CONSUMPTION

NOTES

Only refer to this customer complaint after having performed a complete test using the XR25

Check there are no fuel leaks.
Repair if necessary.
Does the fault persist?

no

End of fault finding.

yes

Check the idle speed
(# 06 on the XR25).
Is it correct?

no

Refer to fault chart 4 or 5, idle problems
(Idle speed too fast or too slow).

yes

Check the vehicle complies with its definition
and is in good condition.
Repair if necessary.
Does the fault persist?

no

End of fault finding.

yes

Check the value of the pollutants and
Lambda.

- CO < 0.3 %
 - HC ≤ 100 ppm
 - CO2 ≥ 14.5 %
 - 0.97 ≤ Lambda ≤ 1.03
- Is it correct?

no


- Check:
- the catalytic converter (melted, blocked, ...).
 - the oxygen sensor (polluted, heating faulty, ...).
 - air leak upstream of the oxygen sensor.
 - the seal of the exhaust pipe.
 - the type of fuel used.
 - the ignition (spark plugs, high voltage leads, coils).
 - the general condition of the engine (timing, ...).

yes

A

AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check


Chart 11
CONT**AFTER REPAIR**

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 12

ENGINE NOISE
Pinking**NOTES**

Only refer to this customer complaint after having performed a complete test using the XR25

**AFTER REPAIR**

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 12
CONT**A**

Check the conformity of the routing of the inlet air pipes.
Repair if necessary.
Does the fault persist?

no

End of fault finding.

yes

Using a stroboscopic light and the XR25, #51,
check the ignition advance
Are the values the same?

no

Refer to bargraph 5 RH fault chart.

yes



This is not an injection problem.
Also check the engine cooling. The
combustion chambers may have to be
cleaned.

AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check









NOTES

Engine cold, ignition on

Order of operations	Function to be checked	Action	Bargraph	Display and Notes
1	Dialogue with XR25	D13 (selector on S8)		9.NJ Use fiche n° 27 fault test side
2	Interpretation of normally illuminated bargraphs		<div>1</div>  <div>1</div> 	Fault test Code present
3	Conformity of computer	G70*		X X X X Part Number number displayed in three sequences (refer to section 12)
4	Switching to status test	G01*		10.NJ Use fiche n° 27 status test side

NOTES

Engine cold, ignition on

Order of operations	Function to be checked	Action	Bargraph	Display and Notes
5	Interpretation of normally illuminated bargraphs		1	Code present
				
			2	No load recognition
				
			4	Receiving + after ignition information
				
			4	Illuminated for automatic transmission whatever the position of the gear lever
				
			5	Locking relay command effective (Do not take this information into account)
				
			11	Camshaft sensor information not effective (Do not take this information into account)
				
			19	Computer configured to work with: Manual gearbox (G60*)
				
			19	Automatic transmission (G50*)
				

NOTES

Engine cold, ignition on

Order of operations	Function to be checked	Action	Bargraph	Display and Notes
6	Throttle position potentiometer	No load # 17	<div>2</div> <div> </div>	$8 < X < 38$
		Accelerator pedal lightly pressed	<div>2</div> <div> </div>	
		Full load # 17	<div>2</div> <div> </div>	$188 < X < 246$
7	Absolute pressure sensor	# 01		$X = \text{Local atmospheric pressure}$
8	Coolant temperature sensor	# 02		$X = \text{Ambient temperature} \pm 5^{\circ}\text{C}$
9	Air temperature sensor	# 03		$X = \text{Ambient temperature} \pm 5^{\circ}\text{C}$
10	Idle regulation solenoid valve	# 12		The value read is fixed and between $17 \% < X < 99.9 \%$
11	Engine speed	# 06		$X = 0 \text{ rpm}$
12	Canister bleed	# 23		$X = 0.7 \%$









NOTES

Engine warm, at idle speed after the fan unit has operated at least once (air conditioning and heated windscreen not selected, automatic transmission in Park or Neutral position)

Order of operations	Function to be checked	Action	Bargraph	Display and Notes
1	Switching to status test	G01*		<div>10.NJ</div> <p>Use fiche n° 27 status test side</p>
2	No fault		<div>20</div> <div> <div></div> <div></div> </div>	<p>Check this bargraph is not flashing; otherwise type G02* and turn the fiche over. Repair the faulty component then erase the fault memory (G0**) and return to status test (G01*)</p>
3	Battery voltage	<p># 04</p> <p>if in # 04</p> <p>otherwise in # 06</p>		<p>13 volts < X < 14.5 volts</p> <p>X < 12.7 volts</p> <p>Nominal engine speed < X < 910 rpm.</p>





NOTES

Engine warm, at idle speed after the fan unit has operated at least once (air conditioning and heated windscreen not selected, automatic transmission in Park or Neutral position)

Order of operations	Function to be checked	Action	Bargraph	Display and Notes
4	Interpretation of the normally illuminated bargraphs	—	<div>1</div> <div></div> <div>2</div> <div></div> <div>3</div> <div></div> <div>4</div> <div></div> <div>4</div> <div></div> <div>5</div> <div></div> <div>6</div> <div></div> <div>6</div> <div></div>	<p>Code present</p> <p>No load recognition</p> <p>Receiving engine speed information</p> <p>Receiving + after ignition information</p> <p>Illuminated in Park or Neutral position</p> <p>Locking relay command effective (Do not take this information into account)</p> <p>Idle regulation active</p> <p>Richness regulation active</p>






NOTES

Engine warm, at idle speed after the fan unit has operated at least once (air conditioning and heated windscreen not selected, automatic transmission in Park or Neutral position)

Order of operations	Function to be checked	Action	Bargraph	Display and Notes
4 (cont)	Interpretation of normally illuminated bargraphs (cont)	—	<div>7</div> <div></div> <div>11</div> <div></div> <div>flashing</div> <div>19</div> <div></div> <div>19</div> <div></div>	<p>Fuel pump active</p> <p>Camshaft sensor information (Do not take this information into account)</p> <p>Computer configured to work with:</p> <p>Manual gearbox (G60*)</p> <p>Automatic transmission (G50*)</p>

NOTES

Engine warm, at idle speed after the fan unit has operated at least once (air conditioning and heated windscreen not selected, automatic transmission in Park or Neutral position)

Order of operations	Function to be checked	Action	Bargraph	Display and Notes
5	Idle speed	<p>Without air conditioning</p> <p># 06</p> <p># 12</p> <p>Air conditioning selected</p> <p># 06</p> <p>Heated windscreen selected. Air conditioning not selected</p> <p># 06</p>	<p>6</p>  <p>9</p>  <p>10</p>  <p>8</p>  <p>9</p> 	<p>$X = 770 \pm 50 \text{ rpm}$</p> <p>$20 \% < X < 40 \% \text{ (F3R 750)}$</p> <p>$18 \% < X < 38 \% \text{ (F3R 751)}$</p> <p>Illuminated depending on the status of the air conditioning</p> <p>$X = 900 \pm 50 \text{ rpm}$</p> <p>If coolant temperature $> 60^{\circ}\text{C}$ when $X = 770 \pm 50 \text{ rpm}$</p> <p>If coolant temperature $< 60^{\circ}\text{C}$ when $X = 1000 \pm 50 \text{ rpm}$</p>
6	Anti-pinking noise measurement	# 13 (3500 rpm, no load)		X variable and not zero

NOTES



Engine warm, at idle speed after the fan unit has operated at least once (air conditioning and heated windscreen not selected, automatic transmission in Park or Neutral position)

Order of operations	Function to be checked	Action	Bargraph	Display and Notes
7	Manifold pressure	# 01 without consumer		X is variable and is around 360 ± 60 mbars (this pressure varies as a function of the altitude)
8	Richness regulation	With stable engine speed of 2500 rpm, then at idle speed # 05 # 35	<div>6</div> <div> <div></div> <div></div> </div> <div>6</div> <div> <div></div> <div></div> </div>	<p>X varies in a range of 50 to 900 mV approximately</p> <p>X is around and varies slightly about 128 with a maximum of 255 and a minimum of 0</p>
9	Adaptive idle correction	# 21		$- 8.6 \% < X < 6.2 \%$ (average value after erasing memory: 0)
10	Canister bleed	# 23	<div>7</div> <div> <div></div> <div></div> </div>	<p>Canister bleed is forbidden. The solenoid valve remains closed</p> <p>$X = 0.7 \%$</p>

- (1) This value is from definitive calibration. The first vehicles marketed have a minimum threshold of $- 6.2 \%$.


NOTES

Test to be performed during a road test

Order of operations	Function to be checked	Action	Bargraph	Display and Notes
1	Switching to status test	G01*		<div>10.NJ</div> Use fiche n° 27 status test side
2	No fault			Check this bargraph is not flashing; otherwise type G02* and turn the fiche over. Repair the faulty component then erase the fault memory (G0**) and return to status test (G01*)
3	Canister bleed	# 23	<div>7</div> 	Canister bleed is authorised X = variable
4	Vehicle speed information	# 18		X = vehicle speed read on the speedometer
5	Pinking sensor	Vehicle loaded and engine speed of 2000 rpm. # 13 # 15		X = variable and not zero $0 \leq X \leq 6$ (if the sensor is faulty, the advance is systematically retarded by 4° which is not visible on # 15)

NOTES

Test to be performed during a road test

Order of operations	Function to be checked	Action	Bargraph	Display and Notes
6	Adaptive richness	After programming phase # 30 # 31		$82 \leq X \leq 224$ (average value after erasing memory: 128) $32 \leq X \leq 224$ (average value after erasing memory: 128)
7	Torque reduction (Automatic transmission)		<div>5</div> 	Illuminated when gear is changed if speed is greater than 6 mph (10 km/h)

SPECIAL TOOLING REQUIRED

OPTIMA 5800 diagnostic station

CHECKING THE IGNITION USING THE DIAGNOSTIC STATION

The OPTIMA 5800 diagnostic station allows the ignition to be checked in two ways:

- **STARTING TEST:** If the vehicle does not start. When no fault finding operations can be performed with the XR25, this operation checks for the presence and the quality of the ignition under the action of the starter motor.
- **TEST WITH ENGINE RUNNING:** These measurements are in addition to those from the XR25 for customer complaints such as: hesitation, misfiring, incorrect gas analysis, unstable idle ...

In addition, the station's measuring module allows static ignition to be checked using two high voltage clamps, where the coils are dual output (when a firing order is given, two sparks are produced simultaneously: one in the cylinder at the combustion phase and the other in the cylinder at the exhaust phase). During the measurements, the two clamps have to be moved from one coil to the other.

Their power is controlled directly by the computer (the amplifier module is integral with the computer): the station is therefore connected directly to the coil inputs.

CONNECTIONS:

- **F3R engine:** Connect to the two coils (blue cable on coil n° 1, located on the left hand side).

MEASUREMENTS:

The ignition is characterised by the following values:

Engine running:

- Spark duration.
- Arcing voltage (or ionising voltage).
- Arcing voltage during the exhaust phase (static ignition).

Starting test:

- Ignition feed voltage.
- TDC sensor signal.
- Command signal (MPA).
- Spark duration.
- Arcing voltage (or ionising voltage).
- Arcing voltage during the exhaust phase (static ignition).

The station checks the coherence of the values obtained for each cylinder, and compares the measurements with a database for each engine type.

SPECIAL TOOLING REQUIRED

OPTIMA 5800 diagnostic station

CHECKING THE OXYGEN SENSOR WITH THE DIAGNOSTIC STATION

Obvious faults relating to the oxygen sensor are detected by the XR25:

- Open circuit.
- Short circuit to earth.
- Short circuit to + 12 V.

The diagnostic station allows operating faults to be highlighted which could not be detected with the XR25. The sensor can be checked for the following customer complaints:


- Excess fuel consumption.
- Irregular idle, hunting.
- Hesitation.
- Incorrect gas analysis.

The station performs the check by being connected in parallel to the signal emitted by the oxygen sensor. This sensor is analysed at a stable engine speed (2 500 rpm), when the richness regulation conditions are concurring (engine warm ...).

CONNECTION:

The 4 track connector of the sensor is located under the vehicle.

During normal operation, the signal is in the form of a sine wave:



The characteristic parameters of this signal are the maximum voltage, the minimum voltage and the period. For all engine types, the correct values are:

- Maximum voltage > 600 mV.
- Minimum voltage < 200 mV.
- Difference (Maximum voltage - minimum voltage) > 500 mV.
- Period < 1 second.

SPECIAL TOOLING REQUIRED

OPTIMA 5800 diagnostic station
4040-5040 or AGM 1500 4 gas analyser

ANALYSING EXHAUST GASES USING THE DIAGNOSTIC STATION

The OPTIMA 5800 diagnostic station connected to an analyser (SOURIAU 4040-5040 or SAGEM AGM 1500) allows the gases to be checked in accordance with the legislation relating to vehicles with catalytic converters. This test is performed at mid-load and at idle speed with the following limits.

Idle speed	2 500 rpm
CO < 0.5 %	CO < 0.3 %
HC < 100 ppm	HC < 100 ppm

Independently to the legislation, other measurements supplied by the analyser fall within certain tolerances:

Idle speed	2 500 rpm
CO ₂ > 13.5 %	CO ₂ > 13.5 %
O ₂ < 0.8 %	O ₂ < 0.8 %
0.97 < Lambda < 1.03	0.97 < Lambda < 1.03

NOTE: Lambda = 1 / Richness

- Lambda > 1 → Lean mixture
- Lambda < 1 → Rich mixture

The condition Lambda = 1 is essential to ensure the catalytic converter functions correctly.

The station causes the following phases:

- Warming up the engine (oil temperature greater than 60°C).
- Holding for one minute at 2 500 rpm. to activate richness regulation and simultaneous gas measurements.
- If the gas analysis at 2 500 rpm is correct, a measurement at idle speed is taken.

If the analysis is deemed to be incorrect by the station, diagnostic messages appear where the priority of the gases is

1) CO 2) Lambda 3) HC 4) O₂ 5) CO₂

NOTE : The report for the whole anti-pollution test can be printed.

SETTING UP A DIALOGUE BETWEEN THE XR25 AND THE COMPUTER

- Connect the test kit to the diagnostic socket.
- Ignition on.
- ISO selector on S6
- Type **D03**

8.INJ**COMPUTER IDENTIFICATION**

The computer is identified by reading the Part Number directly from the computer.
After having set up a dialogue with the computer:

ENTER G70***7700****XXX****XXX**

The Part Number will then appear on the central display in three sequences.

Each sequence is displayed for approximately two seconds. Each sequence is repeated twice. (To find the number, refer to the Workshop Repair Manual, section 12).


ERASING THE MEMORY (engine off, ignition on)

After the injection system has been worked on, the computer's memory can be erased by using the code G0** (Erasing memorised faults in diagnostic mode D03, ISO selector in position S6, enter G0**).

The memories of other components on the vehicle are not erased when this operation is used.

If information obtained from the XR25 means that electrical continuities have to be checked, connect the bornier M.S. 1048 in place of the injection computer connector to give easy access to the measuring points for the various contacts.

Bornier M.S. 1048



(The M.S. 1048 consists of a 35 track base unit which has an integral printed circuit comprising 35 copper coated areas, numbered from 1 to 35).

Using the wiring diagrams, the tracks connecting the component or components can easily be checked.

IMPORTANT:

- All checks with the bornier M.S. 1048 should only be performed with the battery disconnected.
- The bornier is designed to work with an ohmmeter only. Under no circumstances should a 12 volts supply be connected to the control points.

N°28		S8	code : D 0 3	read : 1 8.nJ
1		COMPUTER	CODE PRESENT	
2		CONNECTION FAULT COMP. → MPA	ENGINE IMMOBILISER * 22	
3		REVERSE FLYWHEEL DATA	FLYWHEEL SIGNAL DEF.	
4			INJECTOR SHORT CIRCUIT	
5		IDLING REG. CIRCUIT	AIR TEMPERATURE CIRCUIT	
6			COOLANT TEMPERATURE CIRCUIT	
7		IGNITION KEY DATA		
8		O2 SENSOR CIRCUIT	PRESSURE SENSOR CIRCUIT	
9		COMP. CONNECTION A.T. → INJ	VEHICLE SPEED CIRCUIT	
10		THROTTLE POT. CIRCUIT	PINKING SENSOR CIRC.	

INJECTION

1.nJ Erase memory : disconnect battery
8.nJ Erase memory : G 0 * *

11		Full load ← THROTTLE POSITION → No load	
12		Illuminates if A.T. select. on P/N	TORQUE ADJUSTEMENT
13		ACTIVE ENGINE IMMOBILISER	PAS PRESSOSTAT ACTIVE
14		FLYWHEEL SIGNAL <input type="checkbox"/> Engine running	
15		PUMP ACTIVE	
16		IDLING REG. ACTIVE	CANISTER PURGE AUTHORIZED
17		SELECTION ↓ AIR CONDITIONING	
18		REQUEST → AUTHORIZATION	
19		+ After IGN. PRESENT if Eng. Immobiliser	RICHNESS REG. ACTIVE
20		THROTTLE VALVE HEATER	XR25 MEMORY 0

ADDITIONAL CHECKS : # . .

- 01 Pressure mb
- 02 Coolant temp. °C
- 03 Air temp. °C
- 04 Computer lead V
- 05 O2 sensor V
- 06 Engine speed rpm
- 12 Idle difference
- 13 Pinking signal
- 14 Speed difference rpm
- 15 Pinking correct. d°
- 16 Atmos. pressure mb
- 17 Throttle pot.
- 18 Vehicle speed km per h
- 30 Auto. correct. of richness under high loads
- 31 Auto. correct. of richness under low loads
- 35 Mixture regulation

Help : V 9
Return to diag. mode : D
Part No. : G 7 0 *

SEE REPAIR MANUAL

15 ANG

REPRESENTATION OF THE BARGRAPHS




Illuminates when a dialogue has been established with the product computer. If it remains extinguished:

- the code does not exist,
- there is a fault in the tool, the computer or the line.

REPRESENTATION OF THE FAULTS (always on a coloured background)



If illuminated, indicates a fault on the tested product, the associated text defines the fault.




If extinguished, indicates that the fault has not been found on the tested product.

REPRESENTATION OF THE STATUSES (always on a white background)


Engine off, ignition on, no operator action

The status bargraphs on the fiche are represented as the status which they should have when the engine is off, the ignition is on and there is no operator action

- If on the fiche the bargraph is represented as



the test kit should give as information




- If on the fiche the bargraph is represented as



the test kit should give as information




- If on the fiche the bargraph is represented as



the test kit should give as information


either



or



Engine running



Extinguishes when the function or condition given on the fiche can no longer be performed.



Illuminates when the function or condition given on the fiche is performed.


FUNCTION V9

Fiche n° 28 is a generic fiche used for several engines.

The different engines do not use all the bargraphs. To find out the bargraphs dealt with by the injection computer, after having set up a dialogue with the computer, press the V and 9 buttons simultaneously. The bargraphs dealt with will:

- illuminate permanently for non memorisable fault bargraphs or status bargraphs,
- flash for memorisable fault bargraphs.


To return to fault finding mode, press button D.

<div>1</div> 	<div>Bargraph 1 LH illuminated</div> <div>Fiche n° 28</div> <div><u>COMPUTER CIRCUIT</u></div> <div>XR25 assistance: Internal computer fault</div>
--	--

NOTES	None
--------------	------

<div>Computer is not correct or is faulty.</div> <div>Replace the injection computer.</div>

AFTER REPAIR	Carry out a conformity check
---------------------	------------------------------

	<p>Bargraph 1 RH extinguished Fiche n° 28</p> <p><u>XR25 CIRCUIT</u></p> <p>XR25 assistance: no communication, CO, CC EARTH, CC + 12 V</p>
---	--

NOTES	<p>For fault finding, this bargraph should be illuminated after the ignition is turned on</p>
--------------	---

Check:

- all the injection fuses,
- the connection between the XR25 and the diagnostic socket,
- the position of the dial (S6),
- the conformity of the cassette.

Repair if necessary.

Check:

- the presence of + 12 V on track 16 and the earth on track 4 on the diagnostic socket.
- the connection between the XR25 and the diagnostic socket.

Diagnostic socket	11	→	7	XR25
	3	→	3	socket


Repair if necessary.

Connect bornier M.S. 1048 instead of the computer and check the insulation and continuity between the tracks:

Bornier	8	→	11	Diagnostic socket
	18	→	3	Diagnostic socket
	2	→	earth	Earth MH on cylinder head
	3	→	earth	Earth MH between starter and alternator
	30	→	fuse	Engine + after ignition feed fuse
	32	→	fuse	Engine + after ignition feed fuse

Repair.


AFTER REPAIR	<p>Carry out a conformity check</p>
---------------------	-------------------------------------

<div>2</div> 	Bargraph 2 LH illuminated <div>Fiche n° 28</div> MPA CIRCUIT XR25 assistance: CO LINE 27 CC + 12 LINE 27 CC — LINE 27
--	--

NOTES	Bargraph illuminated only when starter activated
--------------	--

<p>Check the connections on the MPA.</p> <p>Repair if necessary.</p> <p>XR25 as a pulse detector, G and Vin.</p> <p>Check that when the starter is activated, there are pulses on track B of the MPA.</p>

There are pulses	Replace the MPA.
------------------	------------------

There are no pulses	<p>Connect bornier MS 1048 in place of the computer and check the insulation and continuity of the line :</p> <p>27 computer  B MPA 2 track connector</p> <p>Repair.</p>
---------------------	---

The fault persists! Replace the computer.


AFTER REPAIR	<p>Erase the computer memory using G0**.</p> <p>Carry out a conformity check</p>
---------------------	--

<div data-bbox="358 237 384 271">2</div> <div data-bbox="401 322 524 390"></div>	<div data-bbox="624 197 1161 248">Bargraph 2 RH illuminated</div> <div data-bbox="1821 197 2004 243">Fiche n° 28</div> <div data-bbox="624 265 1236 311"><u>ENGINE IMMOBILISER CIRCUIT</u></div> <div data-bbox="624 322 1236 452">XR25 assistance: CO or CC EARTH or CC + 12 V LINE 29 OF COMPUTER</div> <div data-bbox="1323 322 2039 452">#22 = 1 def → fault #22 = 2 def → code not programmed #22 = 3 def → 1 def + 2 def</div>
--	--

NOTES	None
--------------	------

<div data-bbox="214 794 1935 839">Connect bornier M5 1048 in place of the computer and check the insulation and continuity of the line :</div> <div data-bbox="388 856 1227 902">Bornier 29 → 5 Decoder unit</div> <div data-bbox="214 947 528 992">Repair if necessary.</div>	
If the fault persists, refer to status bargraph 13 LH side.	


AFTER REPAIR	Erase the computer memory using G0**. Carry out a conformity check
---------------------	---

<div>3</div> 	<div>Bargraph 3 LH illuminated Fiche n° 28</div> <div><u>FLYWHEEL SENSOR INFORMATION CIRCUIT INCORRECTLY CONNECTED</u></div> <div>XR25 assistance: Wires incorrectly connected</div>
--	---

NOTES	None
--------------	------

Check the sensor is correctly connected - wires inverted.

AFTER REPAIR	<div>Erase the computer memory using G0**.</div> <div>Carry out a conformity check</div>
---------------------	--

<div>3</div> 	Bargraph 3 RH illuminated FLYWHEEL SIGNAL FAULT CIRCUIT XR25 assistance: CO or CC EARTH LINES 28 and 11 or INTERFERENCE ON THE LINES
--	---

Fiche n° 28

NOTES	None
--------------	------

Check the resistance of the TDC sensor between terminals A and B → $R = 227 \Omega$

Replace the sensor if necessary.


Connect bornier MS 1048 in place of the computer and check the insulation and continuity of the line :

Computer	11	→	B	TDC sensor
Computer	28	→	A	TDC sensor

Repair if necessary.

If the fault persists, replace the computer.


AFTER REPAIR	Erase the computer memory using G0**. Carry out a conformity check
---------------------	---

	<p>Bargraph 4 RH illuminated Fiche n° 28</p> <p><u>INJECTOR CIRCUIT</u></p> <p>XR25 assistance: CC + 12 ON LINE 21</p>
---	---

NOTES	<p>Bargraph illuminates when starter activated (\approx 10 seconds)</p> <p>Fault not memorised</p>
--------------	---


<p>Disconnect the connector and check the injector resistance $\rightarrow R = 2 \Omega$</p> <p>Replace the injector if necessary.</p>	
<p>Connect bornier MS 1048 in place of the computer and check the insulation and continuity of the line :</p> <p style="text-align: center;">Bornier 21 \longrightarrow 2 Injector</p> <p>Repair if necessary.</p>	
<p>If the fault persists, replace the computer.</p>	

AFTER REPAIR	<p>Erase the computer memory using G0**.</p> <p>Carry out a conformity check</p>
---------------------	--

<div data-bbox="349 240 382 277">5</div> 	<div data-bbox="622 197 1299 311"> Bargraph 5 LH illuminated <u>IDLE SPEED REGULATION CIRCUIT</u> </div> <div data-bbox="1823 203 1998 240">Fiche n° 28</div> <div data-bbox="622 361 1223 398">XR25 assistance: BG 5LH not active</div>
--	---

<div data-bbox="294 571 436 608">NOTES</div>	<div data-bbox="622 576 1998 613">This bargraph does not illuminate, see bargraph 16 LH side, incorrect illumination.</div>
---	---

<div data-bbox="229 2644 513 2680">AFTER REPAIR</div>	<div data-bbox="622 2672 709 2709">None</div>
--	---

<div>5</div> 	<div>Bargraph 5 RH illuminated</div> <div>Fiche n° 28</div> <div><u>AIR TEMPERATURE CIRCUIT</u></div> <div>XR25 assistance: CO LINE 14 or CC EARTH LINE 14 #03 = - 40</div> <div>CC + 12 LINE 14 #03 = - 119</div> <div>CO LINE 17 #03 = - 40 (see reference)</div>
--	---

NOTES	If BG 6RH is illuminated and BG 11RH is incorrectly illuminated, there is an open circuit on line 17. Refer to BG 5RH
--------------	---

Check the resistance of the air temperature sensor (see section 12 "Specifications").

Replace it if necessary.

Connect bornier **MS 1048** in place of the computer and check the insulation and continuity of the line :

Bornier	14	→	1	Sensor
Bornier	17	→	4	Sensor

Repair if necessary.

If the fault persists, replace the computer.

AFTER REPAIR	Erase the computer memory using G0**. Carry out a conformity check
---------------------	---

6

**Bargraph 5 RH illuminated**

Fiche n° 28

COOLANT TEMPERATURE SENSOR

XR25 assistance: CO LINE 14 or CC EARTH LINE 14 #03 = - 40
CC + 12 LINE 14 #03 = - 119

NOTES

If BG 5RH is illuminated and BG 11RH is incorrectly illuminated. Refer to BG 5RH

Check the resistance of the coolant temperature sensor (see section 12 "Specifications").

Replace it if necessary.

Connect bornier **MS 1048** in place of the computer and check the insulation and continuity of the line :


Bornier	14	→	2	Sensor
Bornier	17	→	1	Sensor

Repair if necessary.

If the fault persists, replace the computer.

AFTER REPAIR

Erase the computer memory using G0**.
Carry out a conformity check

	Bargraph 7 LH illuminated <u>IGNITION KEY INFORMATION CIRCUIT</u> XR25 assistance: CO LINE 30 Fiche n° 28
---	--

NOTES	Bargraph illuminated when ignition is on.
--------------	---

<p>Check the engine connection unit fuse.</p> <p>Connect bornier MS 1048 in place of the computer and check the insulation and continuity of line 30 on the computer.</p> <p>Repair the fuse and the wiring if necessary.</p> <p>If the fault persists, replace the computer.</p>

AFTER REPAIR	Erase the computer memory using G0* [†] . Carry out a conformity check
---------------------	--

<div style="text-align: center;">8</div> <div style="border: 1px solid black; width: 50px; height: 50px; margin: 10px auto;"></div>	<div style="display: flex; justify-content: space-between;"> <div> <p>Bargraph 8 LH illuminated</p> <p><u>OXYGEN SENSOR CIRCUIT</u></p> <p>XR25 assistance: CO LINE 35 or CC EARTH LINE 35 #05 = 0000 #35 = 128</p> <p style="padding-left: 150px;">CC + 12 LINE 35 #05 = 1.530 #35 = 128</p> </div> <div style="text-align: right;">Fiche n° 28</div> </div>
---	---

NOTES	If BG 10LH is illuminated, refer to BG 10LH.
--------------	--

<p>Check the resistance of the oxygen sensor</p> <p>Replace the sensor if necessary.</p>	<p>track A and earth $\rightarrow R \approx 1.5 \Omega$</p> <p>tracks B and C $\rightarrow R \approx \infty$</p>
<p>Engine running, check for $+12 \text{ V}$ between tracks A and B on the sensor connector.</p> <p>Repair the wiring if necessary.</p>	
<p>Connect bornier MS 1048 in place of the computer and check the insulation and continuity of the line :</p> <p>Bornier 35 \longrightarrow C Oxygen sensor connector</p> <p>Repair the wiring if necessary.</p>	
<p>If the fault persists, replace the oxygen sensor.</p>	
<p>If the fault persists, replace the computer.</p>	

AFTER REPAIR	Erase the computer memory using G0**. Carry out a conformity check
---------------------	--

8



Bargraph 8 RH illuminated PRESSURE SENSOR CIRCUIT

Fiche n° 28

XR25 assistance: CO LINE 33

CC EARTH LINE 33

#01 = 1021 IGNITION ON

NOTES

None

Check the sensor is connected electrically and pneumatically.

Repair if necessary.

Ignition on, check for 5 V between tracks C and A on the sensor.

There is not
+ 5 V.Connect bornier **MS 1048** in place of the computer and check the insulation and continuity of the line :

Sensor	A	→	17	Bornier
Sensor	C	→	16	Bornier

If the fault persists, replace the computer.

There is + 5 V.

Connect bornier **MS 1048** in place of the computer and check the insulation and continuity of the line :

Sensor	B	→	33	Bornier
--------	---	---	----	---------


Repair if necessary.

If the fault persists, replace the sensor.

If the fault persists, replace the computer.

AFTER REPAIR

Erase the computer memory using G0**.
Carry out a conformity check

<div data-bbox="355 248 377 277">9</div> 	<div data-bbox="622 206 1268 319">Bargraph 9 RH illuminated <u>VEHICLE SPEED SENSOR CIRCUIT</u></div> <div data-bbox="1823 214 2000 248">Fiche n° 28</div> <div data-bbox="622 367 1384 404">XR25 assistance: CO or CC LINE 3</div>
--	--

NOTES	None
--------------	------

Carry out a road test and check the speed on the speedometer .
If the speed is zero, repair the wiring of track 3 of the computer and B1 of the sensor.
Check the connection and the feed of the speed sensor: + 12V on track A earth on track B2
Repair if necessary.
If the fault persists, replace the speed sensor.

AFTER REPAIR	Erase the computer memory using G0**. Carry out a road test. Carry out a conformity check.
---------------------	--

10

**Bargraph 10 LH illuminated**
THROTTLE POSITION CIRCUIT

Fiche n° 28

XR25 assistance : CO LINE 9 or CC EARTH LINE 9
CO LINE 16

#17 = 128

#01 = 1021 and #17 = 128

NOTES

If BG 8LH is illuminated, there is an open circuit on line 16, refer to BG 10LH

Use an ohmmeter to check the resistance of the potentiometer between tracks:

1 and 2 \approx 4 400 Ω 1 and 4 \approx 1 870 Ω for no load and 4 380 for full load

Replace it if necessary.

Connect bornier MS 1048 in place of the computer and check the insulation and continuity of the line :

Bornier	17	→	1	Sensor
Bornier	16	→	2	Sensor
Bornier	9	→	4	Sensor

Repair the wiring if necessary.

If the fault persists, replace the computer.

AFTER REPAIR

Erase the computer memory using G0**

Carry out a conformity check

10

**Bargraph 10 RH illuminated**
PINKING SENSOR CIRCUIT

Fiche n° 28

XR25 assistance : CO LINE 31 or CC EARTH LINE 31

#13 = 0 # 15 = 0

NOTES

The fault is not taken note of at idle speed

Check the sensor connections.

Repair if necessary.

Connect bornier **MS 1048** in place of the computer and check the insulation and continuity of the line :

Sensor	1	→	17	Bornier
Sensor	2	→	31	Bornier

Repair the wiring if necessary.


If the fault persists, replace the sensor.

If the fault persists, replace the computer.

AFTER REPAIR

Erase the computer memory using G0**

Carry out a conformity check

<div>11</div> 	<div>Bargraph 11 LH, 11 RH, incorrect illumination Fiche n° 28</div> <div><u>THROTTLE POSITION CIRCUIT</u></div> <div>XR25 assistance : BG 11LH illuminated for full load BG 11RH illuminated for no load BG 11LH and BG 11RH extinguished for intermediate position</div>
---	---


NOTES	No fault bargraph should be illuminated. If BG 16LH is incorrectly illuminated, refer to BG 16LH.
--------------	--

The fault is not electrical.

Check the mechanical components of the accelerator circuit (cable, accelerator pedal , ...).

AFTER REPAIR	Carry out a conformity check
---------------------	------------------------------

13

**Bargraph 13 LH incorrect illumination**
ENGINE IMMOBILISER CIRCUIT

Fiche n° 28

XR25 assistance :

BG 13LH illuminated, engine immobiliser active

NOTES

Check the use of the correct PLIP if no fault bargraph is illuminated.

Connect bornier **MS 1048** in place of the injection computer.XR25 as a pulse detector, **G** and Vin.

Check for pulses on track 29 of the bornier when the PLIP is pressed

If pulses are noted, replace the injection computer.

If no pulses are noted, refer to the immobiliser fault finding section.

AFTER REPAIR

Erase the computer memory using G0**

Carry out a conformity check

13

Bargraph 3 RH incorrect illumination

Fiche n° 28

POWER ASSISTED STEERING PRESSOSTAT ACTIVE CIRCUIT

XR25 assistance :

BG 13RH illuminated if PAS pressostat active

NOTES

The power assisted steering must be operational for this fault finding

PAS pressostat normally active position, check the continuity between terminals 1 and 2 on the pressostat.

PAS pressostat normally not active position, check the non-continuity between terminals 1 and 2 on the pressostat.

Replace the pressostat if necessary.

Connect bornier **MS 1048** in place of the computer and check the insulation and continuity of the line :

Earth	MH	→	2	Pressostat
Computer	8	→	1	Pressostat

Repair if necessary.

If the fault persists, replace the computer.

AFTER REPAIR

Erase the computer memory using G0**

Carry out a conformity check


<div style="text-align: center; font-weight: bold;">14</div> <div style="border: 1px solid black; width: 50px; height: 50px; margin: 10px auto;"></div>	<div style="display: flex; justify-content: space-between;"> <div style="width: 60%;"> <p>Bargraph 14 LH incorrect illumination</p> <p><u>FLYWHEEL SIGNAL CIRCUIT</u></p> <p>XR25 assistance :</p> <p style="margin-left: 20px;">BG 14LH illuminated when ignition is turned on</p> <p style="margin-left: 20px;">BG 14LH extinguished during starting phase</p> </div> <div style="width: 35%; text-align: right;"> <p>Fiche n° 28</p> </div> </div>
---	--

NOTES	Dealt with in fault bargraphs section
--------------	---------------------------------------

<div style="text-align: center;">15</div> <div style="border: 1px solid black; width: 50px; height: 30px; margin: 10px auto;"></div>	<div style="text-align: right;">Fiche n° 28</div> <div style="text-align: center;"> Bargraph 15 LH incorrect illumination <u>FUEL PUMP CONTROL CIRCUIT</u> </div>
	<div> XR25 assistance : <div style="margin-left: 100px;"> BG 15LH illuminated when fuel pump relay operated </div> </div>

NOTES	Dealt with in fault bargraphs section
--------------	---------------------------------------

AFTER REPAIR	None
---------------------	------

	<p>Bargraph 16 LH incorrect illumination Fiche n° 28</p> <p><u>IDLE SPEED REGULATION CIRCUIT</u></p> <p>XR25 assistance : BG 16LH illuminated during idle speed regulation phase</p>
---	---

NOTES	<p>If BG 16RH is incorrectly illuminated, there is an open circuit on line 25, refer to BG 16RH.</p> <p>This bargraph is used instead of BG 5LH which does not illuminate.</p>
--------------	--

Check the direct current motor is correctly connected.				
Repair if necessary.				
Use an ohmmeter to check the continuity of the motor winding between tracks 1 and 2 $\rightarrow R \approx 8 \Omega$				
Replace the motor if necessary.				
Connect bornier MS 1048 in place of the computer and check the insulation and continuity of the line :				
Motor	1	\longrightarrow	23	Bornier
Motor	2	\longrightarrow	24	Bornier
Repair if necessary.				
If the fault persists, replace the computer.				

AFTER REPAIR	<p>Erase the computer memory using G0**</p> <p>Carry out a conformity check</p>
---------------------	---

16

Bargraph 16 RH incorrect illumination

Fiche n° 28

CANISTER BLEED CIRCUIT

XR25 assistance : BG 16RH illuminated when canister bleed authorised
incorrect illumination CO LINE 25

NOTES

If BG 16LH illuminates incorrectly, refer to BG 16RH

Check the direct current motor is correctly connected.

Repair if necessary.

Connect bornier **MS 1048** in place of the computer and check the insulation and continuity of the line :

Bornier	25	→	3	Direct current motor
Bornier	1	→	4	Direct current motor.

Repair.

AFTER REPAIR

Erase the computer memory using G0**


Carry out a conformity check

<div style="text-align: center;">17</div> <div style="border: 1px solid black; width: 50px; height: 20px; margin: 0 auto;"></div> <div style="text-align: center;">18</div> <div style="display: flex; justify-content: space-around;"> <div style="border: 1px solid black; width: 50px; height: 20px;"></div> <div style="border: 1px solid black; width: 50px; height: 20px;"></div> </div>	<div style="text-align: right;">Fiche n° 28</div> <p>Bargraph 17LH, 18LH, 18RH incorrect illumination</p> <p><u>AIR CONDITIONING CIRCUIT</u></p> <p>XR25 assistance :</p> <div style="display: flex; justify-content: space-between;"> <div>17LH illuminated if air conditioning selected</div> <div>18LH illuminated if air conditioning requested</div> <div>18RH illuminated if air conditioning authorised</div> </div>
--	--

NOTES	All fault bargraphs must be dealt with, air conditioning must be fitted on the vehicle and selected
--------------	---


<p>Connect bornier MS 1048 instead of the computer and check the insulation and the continuity between tracks :</p> <div style="display: flex; align-items: center; justify-content: center; margin-top: 10px;"> <div style="text-align: right; margin-right: 10px;">Injection computer</div> <div style="display: flex; align-items: center;"> <div style="text-align: right; margin-right: 5px;">34 20</div> <div style="margin: 0 10px;"> <div style="border-top: 1px solid black; width: 50px;"></div> <div style="border-top: 1px solid black; width: 50px;"></div> </div> <div style="text-align: left; margin-left: 5px;">B4 B5</div> </div> <div style="margin-left: 10px;">Air conditioning control panel</div> </div> <p>Repair if necessary.</p>	
<p>XR25 on voltmeter V , check on track 34 of the bornier for 12 V.</p> <p>If there is not 12 V, refer to the air conditioning fault finding section.</p>	
<p>XR25 on voltmeter V , injection computer connected, check for the presence of 12 V on track B5 of the air conditioning control panel</p>	
<p>If there is not 12 V, replace the injection computer.</p>	
<p>If there is 12 V, refer to the air conditioning fault finding section.</p>	

AFTER REPAIR	<p>Erase the computer memory using G0**</p> <p>Carry out a conformity check</p>
---------------------	---

<div>19</div> <div></div>	<div>Bargraph 19 LH incorrect illumination<div>Fiche n° 28</div></div> <div><u>+ AFTER IGNITION CIRCUIT</u></div> <div>XR25 assistance : BG 19LH illuminated when ignition turned on</div>
--	--


NOTES	Dealt with in fault bargraphs section
--------------	---------------------------------------

AFTER REPAIR	None
---------------------	------

<div>19</div> 	<div>Bargraph 19 RH incorrect illuminationFiche n° 28</div> <div><u>RICHNESS REGULATION CIRCUIT</u></div> <div>XR25 assistance : BG 19RH illuminated when the loop mode is entered incorrect illumination if CO LINE 24</div>
---	--

NOTES	If BG 19RH illuminates incorrectly, refer to BG 16LH.
--------------	---

AFTER REPAIR	None
---------------------	------

<div>20</div> 	<div>Bargraph 20 LH incorrect illumination</div> <div>Fiche n° 28</div> <div><u>THROTTLE BODY HEATING CIRCUIT</u></div> <div>XR25 assistance : BG 20LH illuminated if throttle body heating is active</div>
---	---

NOTES	All fault bargraphs must be dealt with. The engine must be cold Ignition on (unless otherwise specified).
--------------	---

Check for 12 V on 1 of the throttle body heater. Replace the heater if you find 12 V.
Check for 12 V on D5 of the PTC relay. Repair the wiring if you find 12 V.
Check on the PTC relay for : 12 V after ignition → D1 12 V before ignition → D3 Repair the wiring if necessary.
Check for an earth on D2, of this relay. Replace the relay if you find an earth.
Connect bornier MS 1048 in place of the computer and check the insulation and continuity of the line : Computer 10 → D2 PTC relay Repair the line if necessary.
If the fault persists, replace the computer.

AFTER REPAIR	Erase the computer memory using G0** Carry out a conformity check
---------------------	--

NOTES

Only refer to these customer complaint charts after having performed a complete test using the XR25.

STARTING PROBLEMS

	Does not start	Chart 1
	Starts but stalls	Chart 2
	Starting is too long	Chart 3

IDLE PROBLEMS

	Too fast	Chart 4
	Too slow	Chart 5
	Engine unstable	Chart 6
	Hunting	Chart 7

BEHAVIOUR WHEN DRIVING

	Lacks performance	Chart 8
	Misfiring and hesitation	Chart 9

SMOKE - POLLUTION

	Gas analysis not correct	Chart 10
	Testing the oxygen sensor	Chart 11

HIGH PETROL CONSUMPTION

Chart 12

ENGINE NOISE

	Pinking	Chart 13
--	---------	----------

Chart 1

STARTING PROBLEMS
Does not start

NOTES

Only refer to this customer complaint after having performed a complete test using the XR25.

Check the impact sensor is clipped in correctly. Check all the (injection) passenger compartment connection unit and engine fuses. Repair if necessary.
Does the fault persist?

no

End of fault finding

yes

Does the fuel pump make a noise when the ignition is turned on?

yes

See Chart 1A

no

When the ignition is switched on, does the fuel pump relay make a noise?

no

Check for the presence of + 12 V on H1 of this relay.

yes

Connect the bornier instead of the injection computer and check the insulation and the continuity of bornier line 6 relay H2.
Repair.

Check for the presence of 12 V on track H3 of this relay.
Repair if necessary.
If the fault persists

The fault persists, replace the relay.

During the timed phase, check for the presence of 12 V on track H5 of this relay.
Is it correct?

no


Replace the relay

yes

A

AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check


Chart 1
CONT**AFTER REPAIR**

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 1A

STARTING PROBLEMS
Does not start**NOTES**

Only refer to this customer complaint after having performed a complete test using the XR25.

**AFTER REPAIR**

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 2

STARTING PROBLEMS
The engine starts but stalls**NOTES**

Only refer to this customer complaint after having performed a complete test using the XR25.

Ignition on,
on the XR25, check the value of
#12 and 21.
Are these values coherent?

no

Refer to bargraph 14 LH fault chart.

yes

Check the air inlet circuit and the exhaust
pipe.
Repair if necessary.
If the fault persists

Check the fuel flow and pressure.
Repair if necessary [pump, filter, regulator,
pipes, injector (seals) ...]
If the fault persists

There is a problem with the engine
and the injection is not faulty.

AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 3

STARTING PROBLEMS
Starting is too long

NOTES

Only refer to this customer complaint after having performed a complete test using the XR25.

Connect the OPTIMA 5800 diagnostic station and perform a starting test. Does the station detect a fault?

yes

Follow the instructions.

no

Perform a test on the station with the engine running. Does the station detect a fault?

yes

Follow the instructions.

no

Check the fuel flow and pressure
(Refer to vehicle Workshop Repair Manual.
Repair the fuel circuit if necessary (pump,
filter, pipes, regulator, injector...)).
If the fault persists

Check the injector is correctly sealed.
If it is not correctly sealed,
replace the faulty injector.
If the fault persists

There is a problem with the engine and the
injection is not faulty.

AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 4

IDLE PROBLEMS
Idle too fast

NOTES

Only refer to this customer complaint after having performed a complete test using the XR25.

R > theoretical idle speed or #12 < theoretical value
especially power assisted steering pressostat, #02 (coolant temperature)

Check no air is leaking into the manifold
(seals, take-off points on the inlet manifold,
plugs, ...).
Repair if necessary.
If the fault persists

Check on the throttle body that it is up
against the lower mechanical stop (#17 <
theoretical value). Also check the accelerator
control. Repair if necessary.
If the fault persists

Check the fuel pressure is not too high.
Repair if necessary
(injector, pump, pressure regulation,
pipes, ...).
If the fault persists

The injection is not faulty.
Check the engine.

AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 5

IDLE PROBLEMS
Idle too slow

NOTES

Only refer to this customer complaint after having performed a complete test using the XR25.
R < theoretical idle speed or #12 > theoretical value

Connect the OPTIMA 5800 diagnostic station and perform an ignition test with the engine running.
Does the station detect a fault?

yes →

Follow the instructions.

no
↓

Check the fuel flow and pressure
(refer to vehicle Workshop Repair Manual).
Repair the fuel circuit if necessary (pump,
filter, pipes, regulator, injector, ...).
If the fault persists

The injection is not faulty.
Check the engine.

AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 6

IDLE PROBLEMS
Engine unstable

NOTES

Only refer to this customer complaint after having performed a complete test using the XR25.

Perform a gas analysis
(Refer to fault chart 10 - smoke/pollution).
If the fault persists

Connect the OPTIMA 5800 diagnostic station
and perform an ignition test with the engine
running.
Does the station detect a fault?

yes

Follow the instructions.

no

Check the operation of the oxygen sensor
(Refer to fault chart 11 - smoke/pollution).
If the fault persists

Engine idling, check the coherence of #01
(the value read should be less than 500 mbar).
Is it correct?

no

Check the absolute pressure sensor and its
wiring loom. Repair,
and if necessary replace the sensor.

yes

Check the fuel flow and pressure
(refer to vehicle Workshop Repair Manual).
Repair the fuel circuit if necessary (pump,
filter, pipes, regulator, injector, ...).
If the fault persists

A

AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 6
CONT**A**

Check the seal and the flow of the injector.
Repair if necessary.
If the fault persists

Check the general condition of the engine
using engine compression tests with the
OPTIMA 5800 station.

AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 7

IDLE PROBLEMS
Hunting**NOTES**

Only refer to this customer complaint after having performed a complete test using the XR25.

Perform a gas analysis
(Refer to fault chart 10 - smoke/pollution)
If the fault persists

Connect the OPTIMA 5800 diagnostic station
and perform an ignition test with the engine
running.
Does the station detect a fault?

yes

Follow the instructions.

no

Check the operation of the oxygen sensor
(Refer to fault chart 11 - Smoke/pollution).
If the fault persists

Check there is no air leak on the inlet
manifold and check the operation of the
injector (seizing...).

AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 8

BEHAVIOUR WHEN DRIVING
Lacks performance

NOTES

Only refer to this customer complaint after having performed a complete test using the XR25.

Check the throttle opens fully
(full load bargraph illuminated).
Check the adjustment of the accelerator
control. Repair if necessary.
If the fault persists

Check the air filter: dirty, deformed. Repair if
necessary.
If the fault persists

Connect the OPTIMA 5800 diagnostic station
and perform an ignition test with the engine
running.
Does the station detect a fault?

yes

Follow the instructions.

no

Perform a gas analysis
(Refer to fault chart 10 - Smoke/pollution).
If the fault persists

Connect the OPTIMA 5800 diagnostic station
and perform an engine compression test
Is it normal?

no


There is a problem with the engine.

yes

A

AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 8
CONT**AFTER REPAIR**

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 9

BEHAVIOUR WHEN DRIVING
Misfiring and hesitation**NOTES**

Only refer to this customer complaint after having performed a complete test using the XR25.

Perform a road test if possible to highlight the fault.
If the fault is reproduced

Connect the OPTIMA 5800 diagnostic station and perform an ignition test with the engine running.
Does the station detect a fault?

yes

Follow the instructions.

no

Perform a gas analysis
(Refer to fault chart 10 - smoke/pollution).
If the fault persists

Check the oxygen sensor
(Refer to fault chart 11 - Smoke/pollution).
If the fault persists


Check for the presence and the cleanliness of the restriction in the absolute pressure sensor pipe.
Repair if necessary.
If the fault persists

Check the seal of the injector, and the fuel flow and pressure (refer to Workshop Repair Manual). Repair if necessary.
If the fault persists

A

AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

**AFTER REPAIR**

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 10

SMOKE - POLLUTION
Gas analysis not correct**NOTES**

Only refer to this customer complaint after having performed a complete test using the XR25.

Connect the OPTIMA 5800 diagnostic station and connect it to a 4040, 5040 or AGM 1500 type 4 gas analyser. Perform an anti-pollution/ gas analysis test. Does the station detect a fault?

no

End of fault finding using fault chart 10
NOTE: a correct gas analysis indicates that the catalytic converter is working correctly.

yes

Is the CO too high (CO > 0.5 when idling or CO > 0.3 at 2500 rpm.) ?

yes

Check the oxygen sensor
(Refer to fault chart 11 - Smoke/pollution).
If the fault persists.

no


Check there is not a problem with the engine
by performing a compression test
(OPTIMA 5800 diagnostic station).

Check the catalytic converter (efficient, fusion, presence of lead, ...), the air supply (filter, manifold, ...), and the condition of the engine (abnormal oil consumption).

A

AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 10
CONT 1**AFTER REPAIR**

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check





Chart 10
CONT 3**AFTER REPAIR**

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 11

SMOKE - POLLUTION
Testing the oxygen sensor**NOTES**

Only refer to this customer complaint after having performed a complete test using the XR25, especially the following parameters:

- #35 (richness correction): this should oscillate around 128
- #30 and #31 (adaptive richness): under no circumstances should they be at their limits.

Connect the OPTIMA 5800 diagnostic station and perform an anti-pollution / oxygen sensor test.
Does the station detect a fault?

no

End of fault finding using fault chart 11.
The oxygen sensor is not faulty.

yes

Check the sensor heating:
- presence of + 12 V at the connector with the engine running,
- the sensor heating resistor is not in an open circuit or short circuited to earth.
If the heating is correct

Is the minimum voltage too high?
($U_{min} > 300 \text{ mV}$; signal offset towards richness).

yes

Connect the OPTIMA 5800 diagnostic station and perform an ignition test with the engine running.
If the station does not detect a fault

no


Check the fuel pressure (regulator), the injector (seal,...) the anti-evaporation circuit (canister) and the fuel grade.
Repair if necessary.
If the fault persists

Replace the sensor.


A

AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 11
CONT 1**AFTER REPAIR**

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 11
CONT 2**AFTER REPAIR**

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 12

HIGH FUEL CONSUMPTION

NOTES

Only refer to this customer complaint after having performed a complete test using the XR25.

Check there are no fuel leaks.
Repair if necessary.
If the fault persists

Check the idle speed
(#06 on XR25).
Is it correct?

no

Refer to fault chart 4 or 5, idle problems
(idle speed too fast or too slow).

yes

Check the vehicle complies with its definition
and is in good condition.
Repair if necessary.
If the fault persists

Perform a gas analysis
(Refer to fault chart 10 - smoke/pollution).
If the fault persists

Check the operation of the O₂ sensor
(Refer to fault chart 11 - Smoke/pollution).
If the fault persists

A

AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 12
CONT**A**

Connect the OPTIMA 5800 diagnostic station
and perform an engine compression test.
Is it normal?

no

There is a problem with the engine.

yes

Check the petrol flow and pressure
(methods, refer to vehicle Workshop Repair
Manual) and the canister bleed circuit.
Repair if necessary
(regulator, pump, filter, pipes).
Does the fault persist?

yes

This is not an injection problem, there is a
problem with the engine.

Check:

- engine oil level
- coolant
- axle assemblies
- the general condition of the engine.

If necessary, perform a consumption test with
the ECONOTEST consumption device.

AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 13

ENGINE NOISE
Pinking**NOTES**

Only refer to this customer complaint after having performed a complete test using the XR25.

Perform a road test with the XR25 and check
13, 15.
Is the fault reproduced?

no

The customer must use his vehicle under
specific conditions, check with the customer.

yes

Perform a gas analysis
(Refer to fault chart 10 - Smoke/pollution).
If the fault persists

Check the operation of the O₂ sensor
(Refer to fault chart 11 - Smoke/pollution).
If the fault persists

Ask the customer what type of fuel he uses.
Is it suitable?

no

Remind the customer what type of fuel he
should use.

yes

Check the condition and the conformity of
the spark plugs.
Replace the spark plugs if necessary.
Does the fault persist?

yes

A

AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 13
CONT**A**

Check the conformity: of the routing of the
inlet air pipes and the air filter.
Repair if necessary.
Does the fault persist?

yes

Using a stroboscopic light and the XR25, #51,
check the ignition advance
Are the values the same?

no

Refer to bargraph 5 RH fault chart.

yes

This is not an injection problem.
Also check the engine cooling. The
combustion chambers may have to be
cleaned.

AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

NOTES

Only refer to these customer complaints after having performed a complete test using the XR25

STARTING PROBLEMS

	Does not start	Chart 1
	Starts but stalls	Chart 2
	Starting is too long	Chart 3

IDLE PROBLEMS

	Too fast	Chart 4
	Too slow	Chart 5
	Engine unstable	Chart 6
	Hunting	Chart 7

BEHAVIOUR WHEN DRIVING

	Lacks performance	Chart 8
	Misfiring and hesitation	Chart 9

SMOKE - POLLUTION

	CO and/or HC too high	Chart 10
--	-----------------------	----------

HIGH PETROL CONSUMPTION

Chart 11

ENGINE NOISE

	Pinking	Chart 12
--	---------	----------



The method without the OPTIMA station does not comply with a sufficient quality criterion.
Use the method with the OPTIMA station to obtain this quality criterion.

Chart 1

STARTING PROBLEMS
Does not start

NOTES

Only refer to this customer complaint after having performed a complete test using the XR25

Check all the injection fuses in the passenger compartment and engine connection units.
Repair if necessary.
Does the fault persist?

no

End of fault finding

yes

Does the fuel pump make a noise when the ignition is turned on?

yes

See Chart 1A

no

Does the fuel pump relay make a noise when the ignition is turned on?

no

Check for - 12 V on H1 of this relay.
Repair.

yes

Connect bornier **MS 1048** in place of the injection computer and check the insulation and continuity of the line 6 bornier H2 relay.
Repair.

The fault persists, replace the relay.

Check for the presence of 12 V on track H3 of this relay.
Repair if necessary.
If the fault persists

During the timed phase, check for the presence of 12 V on track H5 of this relay.
Is it correct?

no


Replace the relay.

yes

A

AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check


Chart 1
CONT**AFTER REPAIR**

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check


Chart 1A

STARTING PROBLEMS
Does not start**NOTES**

Only refer to this customer complaint after having performed a complete test using the XR25.

**AFTER REPAIR**

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**


Chart 1A
CONT**AFTER REPAIR**

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**

Chart 2

STARTING PROBLEMS
The engine starts but stalls**NOTES**

Only refer to this customer complaint after having performed a complete test using the XR25

**AFTER REPAIR**

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 3

STARTING PROBLEMS
Starting is too long**NOTES**

Only refer to this customer complaint after having performed a complete test using the XR25

Check the ignition,
high voltage circuit and spark plugs.
Repair if necessary.
Does starting still take too long?

no

End of fault finding.

yes

Check the fuel flow and pressure,
(method: refer to vehicle Workshop Repair
Manual).
Replace the faulty parts if necessary
(regulator, filter, pump, pipes, ...).
If the fault persists

Check the seal of the injector.
If the seal is not correct,
replace the faulty injector.
The fault persists!

This is an engine problem
and the injection is not faulty.

AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 4

IDLE PROBLEMS
Idle too fast

NOTES

Only refer to this customer complaint after having performed a complete test using the XR25.
R > theoretical idle speed or #12 < theoretical value

Check there is no air leak on the inlet (seals, take-off points on the inlet manifold, plugs, ...).
Repair if necessary.
If the idle speed is too high

Check on the throttle body that it is up against the lower mechanical stop (#17 < theoretical value). Also check the accelerator control. Repair if necessary.
If the idle speed is too high

Check the fuel pressure is not too high.
Repair if necessary
(injector, pump, pressure regulator, pipes, ...).
The fault persists

The injection is not faulty.
Check the engine.

AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 5

IDLE PROBLEMS
Idle too slow

NOTES

Only refer to this customer complaint after having performed a complete test using the XR25
R > theoretical idle speed or #12 < theoretical value

Check the ignition, high voltage leads, spark
plugs and power stages.
Repair if necessary.
If the idle speed is too low

Check the fuel pressure is not too low.
Repair if necessary
(injector, pump, regulator,
pipes, ...).
The fault persists!

The injection is not faulty.
Check the engine.

AFTER REPAIR


Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 6

IDLE PROBLEMS
Engine unstable


NOTES

Only refer to this customer complaint after having performed a complete test using the XR25



AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check


Chart 6
CONT**AFTER REPAIR**

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 7

IDLE PROBLEMS
Hunting**NOTES**

Only refer to this customer complaint after having performed a complete test using the XR25

**AFTER REPAIR**

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 8

BEHAVIOUR WHEN DRIVING
Lacks performance

NOTES

Only refer to this customer complaint after having performed a complete test using the XR25

Check the throttle opens fully
(full load bargraph illuminated).
Check the adjustment of the accelerator
control.
Repair if necessary.
Is there a lack of performance?

no

End of fault finding.

yes

Check the conformity of the spark plugs and
their condition.
Repair if necessary.
Is there a lack of performance?

no

End of fault finding.

yes

Check the value of the pollutants and
Lambda.

- $CO < 0.3 \%$
 - $HC \leq 100 \text{ ppm}$
 - $CO_2 \geq 14.5 \%$
 - $0.97 \leq \text{Lambda} \leq 1.03$
- Is it correct?

no

Check:

- the catalytic converter (melted, blocked, ...).
- the oxygen sensor (polluted, heating faulty, ...).
- air leak upstream of the oxygen sensor.
- the seal of the exhaust pipe.
- the type of fuel used.
- the ignition (spark plugs, high voltage leads, coils).
- the general condition of the engine (timing, ...).

yes

Check the air inlet circuit (air filter,...) and the
exhaust pipe.
Repair if necessary.
Is there a lack of performance?

no


End of fault finding.

yes

A

AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 8
CONT**AFTER REPAIR**


Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 9

BEHAVIOUR WHEN DRIVING
Misfiring and hesitation

NOTES

Only refer to this customer complaint after having performed a complete test using the XR25



AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 9
CONT

A

Disconnect the oxygen sensor and wait for
#35 to stabilise at 128 and #05 = 0.402, and
for bargraph 8 LH to illuminate.
Perform a road test.
Does the engine misfire and hesitate?

no

Replace the oxygen sensor.

yes

Check the condition of the flywheel target.
Repair if necessary.
Does the engine misfire and hesitate?

no

End of fault finding.

yes

Check the petrol flow and pressure
(methods, refer to vehicle Workshop Repair
Manual).
Replace the faulty parts (fuel pump,
regulator, filter, pipes ...).
Does the engine misfire and hesitate?

no

End of fault finding.

yes

Clean the injector.
Does the engine misfire and hesitate?

no

End of fault finding.

yes

Check the valves are not clogged.
Clean the valves if necessary.
After cleaning, does the fault persist?

no

End of fault finding.

yes

This is an engine problem,
the injection is not faulty.

AFTER REPAIR


Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 10

SMOKE - POLLUTION
CO and/or HC too high


NOTES

Only refer to this customer complaint after having performed a complete test using the XR25. CO and / or HC too high
CO > 0.3 % - HC > 100 ppm



AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 10
CONT**AFTER REPAIR**

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 11

HIGH PETROL CONSUMPTION

NOTES

Only refer to this customer complaint after having performed a complete test using the XR25

Check there are no fuel leaks.
Repair if necessary.
Is the fuel consumption still high?

no

End of fault finding.

yes

Check the idle speed
(# 06 on the XR25).
Is it correct?

no

Refer to fault chart 4 or 5, idle problems
(idle speed too fast or too slow).

yes

Check the vehicle complies with its definition
and is in good condition.
Repair if necessary.
Is the fuel consumption still high?

no

End of fault finding.

yes

Check the value of the pollutants and
Lambda.

- CO < 0.3 %
- HC ≤ 100 ppm
- CO2 ≥ 14.5 %
- 0.97 ≤ Lambda ≤ 1.03

Is it correct?

no

Check:


- the catalytic converter (melted, blocked, ...).
- the oxygen sensor (polluted, heating faulty, ...).
- air leak upstream of the oxygen sensor.
- the seal of the exhaust pipe.
- the type of fuel used.
- the ignition (spark plugs, high voltage leads, coils).
- the general condition of the engine (timing, ...).

yes

A

AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 11
CONT**AFTER REPAIR**

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 12

ENGINE NOISE
Pinking**NOTES**

Only refer to this customer complaint after having performed a complete test using the XR25

Perform a road test with the XR25
and check # 13, 15.
Is the fault reproduced?

no

The customer must use his vehicle under
specific conditions, check with the customer.

yes

Check the value of the pollutants and Lambda.

- CO < 0.3 %
 - HC ≤ 100 ppm
 - CO₂ ≥ 14.5 %
 - 0.97 ≤ Lambda ≤ 1.03
- Is it correct?

no

Check:

- the catalytic converter (melted, blocked, ...).
- the oxygen sensor (polluted, heating faulty, ...).
- air leak upstream of the oxygen sensor.
- the seal of the exhaust pipe.
- the type of fuel used.
- the ignition (spark plugs, high voltage leads, coils).
- the general condition of the engine (timing, ...).

yes

Ask the customer what type of
fuel he uses.
Is it suitable?

no

Remind the customer what type of fuel he
should use.

yes

Check the condition and the
conformity of the spark plugs.
Replace the spark plugs if necessary.
Does the pinking persist?

no


End of fault finding.

yes

A

AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 12
CONT**AFTER REPAIR**

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check







NOTES

Before checking conformity, check the fault bargraphs are not illuminated.
Engine cold, ignition on.

Order of operations	Function to be checked	Action	Bargraph	Display and Notes
1	Dialogue with XR25	D03 (selector on S6)		<div>8.NJ</div> Use fiche n° 28
2	Conformity of computer	G70*		<div>XXXX</div> Part Number number displayed in three sequences (refer to section 12)
3	Interpretation of normally illuminated bargraphs		<div>1</div> <div></div> <div>11</div> <div></div> <div>14</div> <div></div> <div>15</div> <div></div> <div>19</div> <div></div>	<div>Code present</div> <div>No load recognition</div> <div>No flywheel signal</div> <div>Illuminated during timed period when ignition turned on</div> <div>Presence of + 12 Volts after ignition on the track. Should be illuminated as soon as ignition is turned on and remains self-fed after ignition turned off.</div>

NOTES







Before checking conformity, check the fault bargraphs are not illuminated.
Engine cold, ignition on.

Order of operations	Function to be checked	Action	Bargraph	Display and Notes
4	Throttle position potentiometer	# 17 Full load # 17 (1)	<div>10</div> <div></div> <div>11</div> <div></div> <div>11</div> <div></div>	<div>XXXX</div> <p>X > 45 (maximum 56) This value is given by the position of the idle speed micromotor and depends on local atmospheric pressure</p> <p>192 < X < 210</p>
5	Absolute pressure sensor	# 01	<div>8</div> <div></div>	<div>XXXX</div> <p>X = local atmospheric pressure</p>
6	Coolant temperature sensor	# 02	<div>6</div> <div></div>	<div>XXXX</div> <p>X – ambient temperature + 5°C</p>
7	Air temperature sensor	# 03	<div>5</div> <div></div>	<div>XXXX</div> <p>X = ambient temperature ± 5°C</p>






(1) Verification of full load recognition by accelerator pedal.

NOTES

Before checking conformity, check the fault bargraphs are not illuminated. Engine warm, at idle speed, after at least one operation of the engine cooling fan assembly.





Order of operations	Function to be checked	Action	Bargraph	Display and Notes
8	Idle speed Reading taken with no consumers	# 06 # 17 Air conditioning on # 06	<div>16</div>  <div>17</div>  <div>18</div> 	<div>XXXX</div> <div>700 < XXX < 800 rpm 15 < XX < 32</div> <div>900 ± 50 rpm</div>
9	Battery voltage	# 04		<div>XXXX</div> <div>12 < XX < 14 Volts</div>
10	Pinking sensor	Accelerate with no load to 3500 rpm approximately # 13	<div>10</div> 	<div>XXXX</div> <div>XX = value read is not zero and is variable</div>
11	Canister bleed	At idle speed At no load and / or stable speed	<div>16</div>  <div>16</div> 	

Before checking conformity, check the fault bargraphs are not illuminated. Engine warm, at idle speed, after at least one operation of the engine cooling fan assembly.

Order of operations	Function to be checked	Action	Bargraph	Display and Notes
12	Absolute pressure sensor	At idle speed, no consumers # 01	<div style="text-align: center;">8</div> 	<div style="border: 1px solid black; padding: 5px; text-align: center;">X X X X</div> <p>X = value read is approximately 370 ± 50 mbar. (Reduces depending on altitude).</p>
13	Oxygen sensor	Check at 2500 rpm stable speed then at idle speed # 05 # 35 If fault # 05 # 35	<div style="text-align: center;">19</div>  <div style="text-align: center;">19</div>  <div style="text-align: center;">8</div> 	<div style="border: 1px solid black; padding: 5px; text-align: center;">X X X X</div> <p>X – value read varies approximately between 50 and 900 mV</p> <p>X = value read varies regularly around 128 with a maximum of 255 and a minimum of 64</p> <p>X = value read remains fixed</p> <p style="text-align: center;">X = 128</p>
14	Power assisted steering pressostat	Turn steering wheel # 06	<div style="text-align: center;">13</div> 	<p style="text-align: center;">825 ± 25 rpm</p>

NOTES

Before checking conformity, check the fault bargraphs are not illuminated.
Check during road test.

Order of operations	Function to be checked	Action	Bargraph	Display and Notes
14	Vehicle speed	# 18	<div>9</div> 	<div>XXXX</div> <p>X = vehicle speed read on speedometer</p>
15	Pinking sensor	Engine speed > 2000 rpm. # 13 # 15 If fault # 15	<div>10</div>  <div>10</div> 	<div>XXXX</div> <p>X = value read is not zero and is variable</p> <p>X = maximum advance retard value of 6°</p> <p>X = 0 (1)</p>
16	Richness regulation (adaptive control)	After driving, engine warm # 05 # 35 # 30 # 31	<div>19</div> 	<div>XXXX</div> <p>X = the value varies regularly between 50 and 900 mV</p> <p>X = the value varies regularly around 128</p> <p>112 < XX < 160 (average value after erasing the memory X = 128)</p> <p>104 < XX < 160 (average value after erasing the memory X = 128)</p>

(1) In defect mode, the advance is retarded by 3 degrees over the complete pinking range (not visible for # 15).

SPECIAL TOOLING REQUIRED
OPTIMA 5800 diagnostic station

CHECKING THE IGNITION USING THE DIAGNOSTIC STATION

The OPTIMA 5800 diagnostic station allows the ignition to be checked in two ways:

- **STARTING TEST:** If the vehicle does not start. When no fault finding operations can be performed with the XR25, this operation checks for the presence and the quality of the ignition under the action of the starter motor.
- **TEST WITH ENGINE RUNNING:** These measurements are in addition to those from the XR25 for customer complaints such as: hesitation, misfiring, incorrect gas analysis, unstable idle ...

CONNECTIONS :

- E7J engine : Directly on to the amplification module (MPA).

MEASUREMENTS:

The ignition is characterised by the following values:

Engine running:

- Spark duration.
- Arcing voltage (or ionising voltage).
- Arcing voltage during the exhaust phase (static ignition).

Starting test:

- Ignition feed voltage.
- TDC sensor signal.
- Command signal (MPA).
- Spark duration.
- Arcing voltage (or ionising voltage).
- Arcing voltage during the exhaust phase (static ignition).

The station checks the coherence of the values obtained for each cylinder, and compares the measurements with a database for each engine type.

SPECIAL TOOLING REQUIRED

OPTIMA 5800 diagnostic station

CHECKING THE OXYGEN SENSOR WITH THE DIAGNOSTIC STATION

Obvious faults relating to the oxygen sensor are detected by the XR25:

- Open circuit.
- Short circuit to earth.
- Short circuit to + 12 V.

The diagnostic station allows operating faults to be highlighted which could not be detected with the XR25. The sensor can be checked for the following customer complaints:


- Excess fuel consumption.
- Irregular idle, hunting.
- Hesitation.
- Incorrect gas analysis.

The station performs the check by being connected in parallel to the signal emitted by the oxygen sensor. This sensor is analysed at a stable engine speed (2 500 rpm), when the richness regulation conditions are concurring (engine warm ...).

CONNECTION:

The 3 track connector of the sensor is located on the clutch bellhousing.

During normal operation, the signal is in the form of a sine wave:



The characteristic parameters of this signal are the maximum voltage, the minimum voltage and the period. For all engine types, the correct values are:

- Maximum voltage > 600 mV.
- Minimum voltage < 200 mV.
- Difference (Maximum voltage - minimum voltage) > 500 mV.
- Period < 1 second.

SPECIAL TOOLING REQUIRED

OPTIMA 5800 diagnostic station
4040-5040 or AGM 1500 4 gas analyser

ANALYSING EXHAUST GASES USING THE DIAGNOSTIC STATION

The OPTIMA 5800 diagnostic station connected to an analyser (SOURIAU 4040-5040 or SAGEM AGM 1500) allows the gases to be checked in accordance with the legislation relating to vehicles with catalytic converters. This test is performed at mid-load and at idle speed with the following limits.

Idle speed	2 500 rpm
CO < 0.5 %	CO < 0.3 %
HC < 100 ppm	HC < 100 ppm

Independently to the legislation, other measurements supplied by the analyser fall within certain tolerances:

Idle speed	2 500 rpm
CO ₂ > 13.5 %	CO ₂ > 13.5 %
O ₂ < 0.8 %	O ₂ < 0.8 %
0.97 < Lambda < 1.03	0.97 < Lambda < 1.03

NOTE: Lambda = 1 / Richness

- Lambda > 1 → Lean mixture
- Lambda < 1 → Rich mixture

The condition Lambda = 1 is essential to ensure the catalytic converter functions correctly.

The station causes the following phases:

- Warming up the engine (oil temperature greater than 60°C).
- Holding for one minute at 2 500 rpm. to activate richness regulation and simultaneous gas measurements.
- If the gas analysis at 2 500 rpm is correct, a measurement at idle speed is taken.

If the analysis is deemed to be incorrect by the station, diagnostic messages appear where the priority of the gases is

1) CO 2) Lambda 3) HC 4) O₂ 5) CO₂

NOTE : The report for the whole anti-pollution test can be printed.

SETTING UP A DIALOGUE BETWEEN THE XR25 AND THE COMPUTER

- Connect the test kit to the diagnostic socket.
- Ignition on.
- ISO selector on S8
- Type **D13**

9.INJ**COMPUTER IDENTIFICATION**

The computer is not identified by reading a fault code but by reading the **Part Number** directly from the computer. After having set up a dialogue with the computer:

ENTER G70***7700****XXX****XXX**

The **Part Number** will then appear on the central display in three sequences..


Each sequence is displayed for approximately two seconds. Each sequence is repeated twice. (To find the number, refer to the Workshop Repair Manual, section 12).

ERASING THE MEMORY (engine off, ignition on)

After the injection system has been worked on, the computer's memory can be erased by using the code **G0**** (Erasing memorised faults in diagnostic mode D13, ISO selector in position S8, enter **G0****).

The memories of other components on the vehicle are not erased when this operation is used.

If information obtained from the XR25 means that electrical continuities have to be checked, connect the bornier **Sus. 1228**.



(The **Sus. 1228** consists of a 55 track base unit which has an integral printed circuit comprising 55 copper coated areas, numbered from 1 to 55).

Using the wiring diagrams, the tracks connecting the component or components can easily be checked.

IMPORTANT:

- All checks with the bornier **Sus. 1228** should only be performed with the battery disconnected.
- The bornier is designed to work with an ohmmeter only. Under no circumstances should a 12 volts supply be connected to the control points.

PRESENTATION OF FICHE N° 27 SIDE 1/2 WITH FAULT BARGRAPHS

N° 27 1/2		S8		code : D 1 3		read : 9 . n J	
1	<input type="checkbox"/> ILLUMINATED → FAULT TEST <input type="checkbox"/> EXTINGUISHED → TURN CARD	CODE PRESENT				<input type="checkbox"/>	
2	<input type="checkbox"/> COMPUTER	ENGINE IMMOBILISER * 22				<input type="checkbox"/>	
3	<input type="checkbox"/> AIR TEMPERATURE	O2 SENSOR * 23				<input type="checkbox"/>	
4	<input type="checkbox"/> COOLANT TEMPERATURE	VEHICLE SPEED				<input type="checkbox"/>	
5	<input type="checkbox"/> PRESSURE	FLYWHEEL SIGNAL * 25				<input type="checkbox"/>	
6	<input type="checkbox"/> * 06 PINKING	THROTTLE POSITION				<input type="checkbox"/>	
7	<input type="checkbox"/> CAMSHAFT	FUEL TANK PRESSURE				<input type="checkbox"/>	
8	<input type="checkbox"/> * 08 FUEL PUMP	BLOCKING * 28				<input type="checkbox"/>	
9	<input type="checkbox"/> * 09 ANTI - PERCOLATION	AIR PUMP * 29				<input type="checkbox"/>	
10	<input type="checkbox"/> * 10 O2 SENSOR OVERHEATING	BI MODE * 30				<input type="checkbox"/>	

INJECTION (faults)

Memory del. : G 0 **
Status check request : G 0 1 *

11	<input type="checkbox"/> * 11 INJECTOR CIRCUIT	CONNECTION A.T. → INJ.	<input type="checkbox"/>
12	<input type="checkbox"/> * 12 WARN. LAMP CIRCUIT FAULT	DATA + FUEL PUMP	<input type="checkbox"/>
13	<input type="checkbox"/> SAVE DATA IN MEMORY		
14	<input type="checkbox"/> * 14 IDLE SPEED REG. CIRCUIT	CANISTER PURGE CIRCUIT * 34	<input type="checkbox"/>
15	<input type="checkbox"/> CONNECTION INJ. → A/C	EGR CIRCUIT * 35	<input type="checkbox"/>
16	<input type="checkbox"/> * 16 IGNITION COILS	COLD START INJECTORS * 36	<input type="checkbox"/>
17	<input type="checkbox"/> * 17 MIL WARNING LIGHT		
18			
19			
20	<input type="checkbox"/> * 20 COMPUTER CONFIGURATION	XR25 MEMORY 0	<input type="checkbox"/>

ADDITIONAL CHECKS : # ..

- | | | |
|----|---|----------|
| 01 | Pressure | mb |
| 02 | Coolant temp. | °C |
| 03 | Air temp. | °C |
| 04 | Computer feed | V |
| 05 | O2 sensor | V |
| 06 | Engine speed | rpm |
| 12 | Idling RCO | % |
| 13 | Pinking signal | |
| 14 | Speed difference | rpm |
| 15 | Pinking correct. | d° |
| 16 | Atmos. pressure | mb |
| 17 | Throttle pot. | |
| 18 | Vehicle speed | km per h |
| 21 | Auto. correct. of RCO idle speed | % |
| 23 | Canister purge RCO | % |
| 24 | RCO EGR | % |
| 30 | Auto. correct. of richness under high loads | |
| 31 | Auto. correct. of richness under low loads | |
| 35 | Mixture regulation | |

END OF TEST : G 1 3 *

Part No. : G 7 0 *

Diagnostic faults :

Press V and 0


Return to diagnostic mode : D

15 ANG


PRESENTATION OF FICHE N° 27 SIDE 2/2 WITH STATUS BARGRAPHS


N° 27 2/2		read : 10.0	
1	ILLUMINATED → EXTINGUISHED ←	STATUS TEST TURN CARD	CODE PRESENT
2	Full Load ← THROTTLE POSITIONS → No load		CONTROL MODES : G .. *
3	FLYWHEEL SIGNAL	ACTIVE ENGINE IMMOBILISER	(If engine stationary)
4	PARK/NEUTRAL POSITION	+ APC COMPUTER	10 Fuel pump relay
5	TORQUE ADJUSTMENT	RELAY CONTROL LOCKING	11 Blocking relay
6	RICHNESS REGULATION	IDLING REGULATION	12 A/C compressor
7	FUEL PUMP CONTROL	CANISTER PURGE AUTHORIZED	14 Idle speed reg. valve
8	ANTI-PERCOLATION CONTROL	ELECT. WINDSCREEN CONTROL	16 Canister purge valve
9	SELECTION	ACCELERATED IDLE SPEED	17 Anti percolation relay
10	REQUEST → AUTHORIZATION		21 Warning lamp fault
			22 Air pump relay
			23 EGR valve
			24 Bi-mode inlet valve
			COMPUTER CONFIGURATION
			(Vehicle with AT or MAN. GEARBOX)
			See procedure in Workshop Manual
			ADDITIONAL CHECKS : # ..
			01 Pressure mb
			02 Coolant temp. °C
			03 Air temp. °C
			04 Computer feed V
			05 O2 sensor V
			06 Engine speed rpm
			12 Idling RCO %
			13 Pinking signal
			14 Speed difference rpm
			15 Pinking correct. d°
			16 Atmos. pressure mb
			17 Throttle pot.
			18 Vehicle speed km per h
			21 Auto. correct. of RCO idle % speed
			23 Canister purge RCO %
			24 RCO EGR %
			30 Auto. correct. of richness under high loads
			31 Auto. correct. of richness under low loads
			35 Mixture regulation
			END OF TEST: G 1 3 *
			Part No. : G 7 0 *
11	SIGNAL CAMSHAFT	BLEED CANISTER + ACTIVE SOL. VALVES	
12	EGR SOLENOID CONTROL	ERASE MEMORISED FAULTS	
13	AIR PUMP CONTROL	POWER STEERING PRESSOSTAT	
14	BI-MODE INLET CONTROL	COLD START INJECTORS	
15			
16			
17			
18			
19	Veh. with AT	COMPUTER CONFIGURATION	Veh. with Man. g/box
20	FAULT PRESENT	XR25 MEMORY	
			Diagnosed faults : Press V and 9 Return to diagnostic mode : D
			15 ANG

REPRESENTATION OF THE BARGRAPHS

-  Illuminates when a dialogue has been established with the product computer. If it remains extinguished:
- the code does not exist,
 - there is a fault in the tool, the computer or the line.








REPRESENTATION OF THE FAULTS (always on a coloured background)

-  If illuminated, indicates a fault on the tested product, the associated text defines the fault.



-  If extinguished, indicates that the fault has not been found on the tested product.

REPRESENTATION OF THE STATUSES (always on a white background)**Engine off, ignition on, no operator action**

The status bargraphs on the fiche are represented as the status which they should have when the engine is off, the ignition is on and there is no operator action

- If on the fiche the bargraph is represented as  the test kit should give as information 
 - If on the fiche the bargraph is represented as  the test kit should give as information 
 - If on the fiche the bargraph is represented as  the test kit should give as information
- either  or 

Engine running

-  Extinguishes when the function or condition given on the fiche can no longer be performed.
-  Illuminates when the function or condition given on the fiche is performed.

FUNCTION V9

Fiche n° 27 side 1/2 and side 2/2 is a generic fiche used for several engines.

The different engines do not use all the bargraphs. To find out the bargraphs dealt with by the injection computer, after having set up a dialogue with the computer, press the V and 9 buttons simultaneously. The bargraphs dealt with will:

- illuminate permanently for non memorisable fault bargraphs or status bargraphs,
- flash for memorisable fault bargraphs.


To return to fault finding mode, press button D.

**GENERAL
NOTES**

If several bargraphs are illuminated, check the insulation of line 48 on the computer from + 12 V.
If the insulation is correct, deal with each of the bargraphs.

AFTER REPAIR

Erase the computer memory using G0**.
Carry out a conformity check

	<p>Bargraph 1 RH extinguished Fiche n° 27 side 1/2</p> <p><u>XR25 CIRCUIT</u></p> <p>XR25 assistance : no connection, CO, CC EARTH, CC + 12</p>
---	---

NOTES	For fault finding, this bargraph should be illuminated
--------------	--

Check:

- all the fuses,
- the connection between the XR25 and the diagnostic socket,
- the presence of + 12 V on track 16 and earth on track 4 of the diagnostic socket.

Repair if necessary.

Check:

- the position of the selector (S8),
- the conformity of the cassette,
- the connection between the XR25 and the diagnostic socket.

Diagnostic socket	15	→	4	XR25
	7	→	8	socket

Repair if necessary.

Connect bornier **Sus. 1228** instead of the computer and check the insulation and continuity between the tracks:


Bornier	38	→	15	Diagnostic socket
	11	→	7	Diagnostic socket
	2	→	earth	Earth MH
	3	→	earth	Earth MH
	24	→	fuse	Engine + after ignition feed fuse
	28	→	3	Coil 1-4
	29	→	3	Coil 2-3

Repair.

Check for + 12 V before ignition on track 32 of the bornier **Sus. 1228**.

Repair.


AFTER REPAIR	Carry out a conformity check
---------------------	------------------------------

<div>2</div> 	<div>Bargraph 2 LH illuminated</div> <div>Fiche n° 27 side 1/2</div> <div><u>COMPUTER CIRCUIT</u></div> <div>XR25 assistance: Computer fault if bargraph 2LH illuminated</div>
--	--


NOTES	None
--------------	------

Computer is not correct or is faulty.
Replace the injection computer.


AFTER REPAIR	Carry out a conformity check
---------------------	------------------------------

<div>2</div> 	<div>Bargraph 2 RH illuminated</div> <div>Fiche n° 27 side 1/2</div> <div><u>ENGINE IMMOBILISER CIRCUIT</u></div> <div>XR25 assistance : CO or CC + 12 V line 35 of the computer</div>
--	--

NOTES	None
--------------	------

<div>Connect the bornier Sus. 1228 instead of the computer and check the insulation and continuity of line:</div> <div>Bornier 35  5 Connector P16 on engine connection unit</div> <div>Repair if necessary.</div>	
If the fault persists, refer to status bargraph 3 RH side.	


AFTER REPAIR	<div>Erase the computer memory using G0**.</div> <div>Carry out a conformity check</div>
---------------------	--

<div style="text-align: center;">3</div> 	<div style="text-align: right;">Fiche n° 27 side 1/2</div> <p>Bargraph 3 LH illuminated</p> <p><u>AIR TEMPERATURE SENSOR CIRCUIT</u></p> <p>XR25 assistance : #03 = -40 CO LINE 20 OR 46 ; CC = 5V LINE 20 #03 = 119 CC LINE 46/20</p>
--	---

NOTES	None
--------------	------

Check the resistance of the air temperature sensor.
If the resistance is not correct, replace the air temperature sensor .
<p>Connect the bornier 5us. 1228 instead of the computer and check the insulation and continuity of the electrical wiring between tracks:</p> <p style="padding-left: 40px;">1 sensor connector 46 bornier 2 sensor connector 20 bornier</p>
If the electrical wiring is correct, replace the computer.


AFTER REPAIR	<p>Erase the computer memory using G0**.</p> <p>Carry out a conformity check</p>
---------------------	--

<div>3</div> 	<div>Bargraph 3 RH illuminated</div> <div>Fiche n° 27 side 1/2</div> <div><u>OXYGEN SENSOR CIRCUIT</u></div> <div>XR25 assistance : #35 = 128 #05 = 0.408 CO LINE 17</div>
--	--

NOTES	None
-------	------

Check the connection and condition of the oxygen sensor connector.
Engine running, check for + 12V between tracks A and B on the oxygen sensor connector.
If there is not – 12V, repair the wiring for the sensor heating circuit.
Ignition off, connect bornier Sus. 1228 in place of the computer and check the continuity and insulation of the wiring between tracks : C/17 and B/18 (sensor connector /bornier) If necessary, repair the wiring.
The fault persists ! Replace the oxygen sensor
The fault persists ! Replace the computer.

AFTER REPAIR	Erase the computer memory using G0*. Carry out a conformity check
--------------	--



Bargraph 4 LH illuminated

Fiche n° 27 side 1/2

COOLANT TEMPERATURE SENSOR CIRCUIT

XR25 assistance: #02 = -40°C CC = 5V LINE 15 ; CO LINE 15 or 44
#02 = 119°C CCEARTH LINE 15 ; CC LINE 15/44

NOTES

If BG5LH is illuminated, refer to BG4RH

If BG3LH ; BG3RH ; BG6RH ; BG12RH are illuminated, refer to BG6RH

Check the resistance of the coolant temperature sensor.

The resistance is not correct, replace the sensor.

Connect the bornier **Sus. 1228** instead of the computer and check the continuity and the insulation of the electrical wiring between the tracks:


1 coolant temperature sensor	44 bornier
2 coolant temperature sensor	15 bornier
C pressure sensor	45 bornier
3 throttle potentiometer	45 bornier

Repair if necessary.

The fault persists! Replace the computer.

AFTER REPAIR


Erase the computer memory using G0**.
Carry out a conformity check

<div data-bbox="366 240 399 277">4</div> 	<div data-bbox="635 200 1174 248">Bargraph 4 RH illuminated</div> <div data-bbox="1690 206 2018 243">Fiche n° 27 side 1/2</div> <div data-bbox="635 268 1286 313"><u>VEHICLE SPEED SENSOR CIRCUIT</u></div> <div data-bbox="635 361 1227 398">XR25 assistance : CO or CC LINE 12</div>
--	--

<div data-bbox="307 574 454 616">NOTES</div>	None
---	------

Carry out a road test and check the speed on the speedometer .
If the speed is zero, repair the wiring of track 12 of the computer and B1 of the sensor.
Check the connection and the feed of the speed sensor: + 12V on track A earth on track B2
Repair if necessary.
The fault persists! Replace the speed sensor.

<div data-bbox="235 2644 530 2686">AFTER REPAIR</div>	Erase the computer memory using G0**. Carry out a road test. Carry out a conformity check
--	---

<p style="text-align: center;">5</p> 	<p style="text-align: right;">Fiche n° 27 side 1/2</p> <p>Bargraph 5 LH illuminated</p> <p><u>ABSOLUTE PRESSURE SENSOR CIRCUIT</u></p> <p>XR25 assistance: #01 = 103 mb CO LINE 16 or LINE 44 or LINE 45; CC EARTH LINE 16</p> <p style="text-align: center;">#01 = 1046 mb CO LINE 44; CC LINE 16 - 45</p>
--	---

NOTES	<p>If BG4LH is illuminated, refer to BG5 LH first</p> <p>If BG6RH is illuminated, refer to BG5 LH first</p>
--------------	---


Check the pressure sensor is electrically and pneumatically connected .	
Ignition on, check that there is + 5V between track C and earth on track A.	

There is not + 5V between track C and track A	<p>Connect the bornier Sus. 1228 instead of the computer and check the insulation and continuity between the tracks:</p> <p style="padding-left: 40px;">A sensor connector 44 bornier</p> <p style="padding-left: 40px;">C sensor connector 45 bornier</p> <p style="padding-left: 40px;">B sensor connector 16 bornier</p>
	Repair if necessary.
	There is not + 5V ! The fault persists! Replace the computer.

There is + 5V between track C and track A	<p>Ignition on, check the return voltage (0.2 to 5 V) on track B of the sensor.</p> <p>Note: For this measurement, a vacuum pump can be used to check the voltage variation.</p>
	If the voltage does not vary, replace the sensor.

The voltage varies	
Connect the bornier Sus. 1228 instead of the computer and check the insulation and the continuity between track B of the sensor and 16 of the bornier.	
Repair if necessary.	
The fault persists! Replace the computer.	


AFTER REPAIR	<p>Erase the computer memory using G0**.</p> <p>Carry out a conformity check</p>
---------------------	--

<div style="text-align: center;">5</div> 	<div style="text-align: right;">Fiche n° 27 side 1/2</div> <p>Bargraph 5 RH illuminated FLYWHEEL SENSOR CIRCUIT</p> <p>XR25 assistance : *25 = CO CO LINE 33 or 34 *25 = CC.O INTERFERENCE *25 = In SENSOR WIRE INVERTED</p>
--	---

NOTES	None
--------------	------

Disconnect the sensor connector and check the resistance of the sensor between terminals A and B.
The resistance is not correct. Replace the sensor.
The resistance is correct.
Connect the bornier Sus. 1228 instead of the computer and check the continuity and the insulation of the wiring between the tracks: <div style="margin-left: 40px;">A sensor 34 bornier B sensor 33 bornier</div>
Repair if necessary.
The fault persists! Replace the computer.

AFTER REPAIR	Erase the computer memory using G0**. Carry out a conformity check
---------------------	---



Bargraph 6 LH illuminated PINKING SENSOR CIRCUIT

Fiche n° 27 side 1/2

```
XR25 assistance : #15 = 0      CO LINE 8  
                  #15 = 0 and #13 = 0 CC LINE 8 } *06 - def
```

NOTES

None

Check the wiring of the faulty sensor.

Repair if necessary.

Connect the bornier **Sus. 1228** instead of the computer and check the insulation and the continuity of the line:


1 sensor	44 bornier
2 sensor	8 bornier

Repair if necessary.

The fault persists! Replace the pinking sensor.

AFTER REPAIR


Erase the computer memory using G0**.
Carry out a conformity check

<div style="text-align: center; margin-bottom: 10px;">6</div> 	<div style="display: flex; justify-content: space-between;"> <div> <p>Bargraph 6 RH illuminated</p> <p><u>THROTTLE POTENTIOMETER CIRCUIT</u></p> <p>XR25 assistance: #17 = 0 CO LINE 45 or 19 or CC EARTH LINE 19 or 45 or CC LINE 19- 46</p> </div> <div style="text-align: right;"> <p>Fiche n° 27 side 1/2</p> </div> </div>
---	--

NOTES	If BG5LH is illuminated, refer to BG6RH
--------------	---

Check the resistance of the throttle potentiometer between tracks 1 and 3 ($R > 4000$ ohms).						
Check the variation of the throttle potentiometer between tracks 1 and 2.						
1-3 < 4000 ohms or 1-2 does not vary. Replace the throttle potentiometer.						
1-3 > 4000 ohms and 1-2 varies.						
Connect the bornier Sus. 1228 instead of the computer and check the insulation and the continuity between tracks:						
<table><tr><td>1 potentiometer</td><td>46 bornier</td></tr><tr><td>3 potentiometer</td><td>45 bornier</td></tr><tr><td>2 potentiometer</td><td>19 bornier</td></tr></table>	1 potentiometer	46 bornier	3 potentiometer	45 bornier	2 potentiometer	19 bornier
1 potentiometer	46 bornier					
3 potentiometer	45 bornier					
2 potentiometer	19 bornier					
Repair if necessary.						
The fault persists! Replace the computer.						

AFTER REPAIR	Erase the computer memory using G0**. Carry out a conformity check
---------------------	---

<div style="text-align: center;">8</div> 	<div style="text-align: right;">Fiche n° 27 side 1/2</div> Bargraph 8 LH illuminated FUEL PUMP RELAY COMMAND CIRCUIT XR25 assistance: *08 = CO.O CO or CC EARTH LINE 48 or 52 *08 = CC.1 CC + 12V LINE 48
--	---


NOTES	None
--------------	------

Check the injection fuses.
Check the impact sensor is correctly clipped in. If it cannot be correctly re-engaged, replace it.
Check for + 12 V on tracks H1 and H3 on the fuel pump relay. Repair the lines if necessary.
During the timed phase, check on the fuel pump relay for an earth on H2.

There is no earth on H2.	Check the insulation and continuity of the line H2 → 48 using bornier Sus. 1228 instead of the computer. Repair if necessary. The fault persists! Replace the injection computer.
--------------------------	---

On this relay, check for + 12 V on H5. Replace the relay if there is not + 12 V.
Connect bornier Sus. 1228 in place of the computer and check the insulation and continuity of the line : H5 relay 52 computer Repair if necessary.
The fault persists! Replace the injection computer.

AFTER REPAIR	Erase the computer memory using G0**. Carry out a conformity check
---------------------	---

<div>11</div> 	<div>Bargraph 11 LH illuminated Fiche n° 27 side 1/2</div> <div><u>INJECTION CIRCUIT</u></div> <div>XR25 assistance: *11 = XX.CO.O CO or CC EARTH LINE 4 or 30</div> <div style="padding-left: 150px;">*11 = XX.CC CC + 12V LINE 4 or 30</div> <div style="padding-left: 150px;">*11 = Def MEMORISED FAULT</div>
---	--


NOTES	XX represents the cylinder N°. Starter motor operating, bargraph illuminates for 10 seconds.
--------------	---

Check the resistance of each injector.

The resistance is not correct	Replace the faulty injector(s).
The resistance is correct	Connect the bornier Sus. 1228 instead of the computer and check the continuity and insulation between the injector connectors on track 2 and tracks 4 and 30.
	Repair the wiring if necessary.

The fault persists! Replace the computer.


AFTER REPAIR	Erase the computer memory using G0**. Carry out a conformity check
---------------------	---

<div data-bbox="375 248 419 282">11</div> <div data-bbox="410 325 541 395"></div>	<div data-bbox="642 206 1201 254">Bargraph 11 RH illuminated</div> <div data-bbox="1692 212 2020 248">Fiche n° 27 side 1/2</div> <div data-bbox="642 274 1950 319"><u>AUTOMATIC TRANSMISSION ---> INJECTION COMPUTER CONNECTION</u></div> <div data-bbox="642 367 2026 449">XR25 assistance: BG 11LH illuminated if there is a connection fault with the automatic transmission</div>
--	---

NOTES	Only if automatic transmission
--------------	--------------------------------

<p>Connect the bornier Sus. 1228 in place of the injection computer, and check the insulation and continuity of computer line 7 .</p> <p>Repair.</p>	<p>The fault persists! Refer to automatic transmission fault finding section.</p>
---	---


AFTER REPAIR	<p>Erase the computer memory using G0**.</p> <p>Carry out a conformity check</p>
---------------------	--

<div style="text-align: center;">12</div> 	<div style="text-align: right;">Fiche n° 27 side 1/2</div> <p>Bargraph 12 LH illuminated</p> <p><u>FAULT WARNING LIGHT CIRCUIT</u></p> <p>XR25 assistance: *12 = CO.O CO or CC EARTH LINE 43 *12 = CC.1 CC + 12V LINE 43</p>
---	---

NOTES	<p>BG12LH only illuminates when there is a fault on the warning light circuit and another fault simultaneously (<i>which normally illuminates the warning light</i>).</p>
--------------	---

Turn on the ignition and check that the fault warning light illuminates for 3 seconds.
If it does not illuminate, check the bulb.
Connect the bornier Sus. 1228 instead of the computer and check the insulation and continuity of line 43 / warning light bulb via R34.
Repair if necessary.
The fault persists! Replace the computer.

AFTER REPAIR	<p>Erase the computer memory using G0**.</p> <p>Disconnect the pressure sensor and check the bargraphs on the XR25.</p> <p>Erase the computer memory and carry out a conformity check</p>
---------------------	---

<p>13</p> 	<p>Bargraph 13 LH illuminated</p> <p><u>MEMORY CIRCUIT</u></p> <p>XR25 assistance: Battery cut</p> <p>Fiche n° 27 side 1/2</p>
---	---

<p>NOTES</p>	<p>Ask if the battery has been removed</p>
---------------------	--

<p>Check:</p> <ul style="list-style-type: none"> - the battery charge, - the injection fuses, - the battery leads. <p>Repair.</p>	<p>Turn the ignition on for 5 seconds, then start the engine.</p> <p>Erase the computer memory using G0**.</p> <p>The fault persists! Replace the computer.</p>
--	---

<p>AFTER REPAIR</p>	<p>Erase the computer memory using G0**.</p> <p>Carry out a conformity check</p>
----------------------------	--

14

**Bargraph 14 LH illuminated**

Fiche n° 27 side 1/2

IDLE SPEED REGULATION CIRCUIT

XR25 assistance: *14 = def #12 ≈ 10 #21 = 0.0 #31 = 1280

CO LINE 9, 35, 36, 40

*14 = def #12 ≈ 10 #21 = -0.3 #31 = 128

CC EARTH LINE 9, 35, 36, 40

NOTES

With no fault #12 should be variable

Check the resistance of the stepping motor coils between :

A and B

C and D

If the resistance is not correct, replace the stepping motor.

Connect bornier Sus. 1228 in place of the computer and check the insulation and continuity of the line :

bornier 35 → A stepping motor

bornier 40 → B stepping motor


bornier 36 → C stepping motor

bornier 9 → D stepping motor

Repair the wiring if necessary.

The fault persists! Replace the computer.

AFTER REPAIRErase the computer memory using G0**.
Carry out a conformity check

14		Bargraph 14 RH illuminated	Fiche n° 27 side 1/2
		CANISTER BLEED CIRCUIT	
XR25 assistance:		*34 = CC.0	#23 = 0.7 CO or CC EARTH LINE 42
		*34 = CC.1	#23 = 0.7 CC - 12V LINE 42
		*34 = Def	MEMORISED FAULT

NOTES	
--------------	--


Check the resistance of the canister bleed valve between tracks A and B.
The resistance is not correct. Replace the canister bleed valve.
The resistance is correct. Engine idling, check for the presence of + 12V on track A of the canister bleed valve.

There is not - 12V on track A	Repair the wiring between track A of the canister bleed valve and wire joint AB in the engine wiring.
----------------------------------	---


There is + 12V on track A	Connect bornier Sus. 1228 instead of the computer and check the insulation and the continuity of the electrical wiring between track B of the canister bleed valve and 42 of the bornier.
	Repair if necessary.

The fault persists! Replace the injection computer.


AFTER REPAIR	Erase the computer memory using G0**. Carry out a conformity check
---------------------	---

<div>15</div> 	<div>Bargraph 15 LH illuminated Fiche n° 27 side 1/2</div> <div><u>AIR CONDITIONING INJECTION CONNECTION CIRCUIT</u></div> <div>XR25 assistance: CC + 12 V on line 51 of the computer</div>
---	--

NOTES	Check that the vehicle has air conditioning and if not, examine the other bargraphs
--------------	---

<div>Connect bornier Sus. 1228 in place of the computer and check the insulation and continuity of the line :</div> <div>Bornier 51  B5 Air conditioning control panel</div> <div>Repair if necessary.</div>	
The fault persists, refer to checking the status bargraphs 9LH, 10LH, 10RH.	

AFTER REPAIR	Erase the computer memory using G0**. Carry out a conformity check
---------------------	---

<div>15</div> 	<div>Bargraph 15 RH illuminated</div> <div>Fiche n° 27 side 1/2</div> <div><u>EGR CIRCUIT</u></div> <div>XR25 assistance: *35 = CO. 0 CO OR CC EARTH LINE 10 *35 = CC. 1 CC + 12 V LINE 10</div>
---	--

NOTES	None
--------------	------

Set the system up to control the EGR.

Check for :


+ 12 V on terminal 2 of the EGR
earth on terminal 1 of the EGR

Repair the wiring.

If the fault persists, replace the EGR.

The fault persists, replace the injection computer.

AFTER REPAIR	Erase the computer memory using G0**. Carry out a conformity check
---------------------	---

<p style="text-align: center;">16</p> 	<p style="text-align: right;">Fiche n° 27 side 1/2</p> <p>Bargraph 16 LH illuminated</p> <p><u>IGNITION COIL CIRCUIT</u></p> <p>XR25 assistance: *16 = 1.4 CC CO ON LINE 28 *16 = 2.3 CC CO ON LINE 29</p>
---	---

NOTES	If there is CC EARTH, the fuse has blown and there is no dialogue with the XR25
--------------	---


Check the resistance of the faulty coil.

The resistance is not correct	Replace the faulty coil.
-------------------------------	--------------------------

The resistance is correct	Connect bornier Sus. 1228 instead of the computer and check the insulation and continuity of line 28/3 for coil 1 or 29/3 for coil 2 (bornier / coil).
	Repair the faulty line.

The fault persists! Replace the computer.


AFTER REPAIR	Erase the computer memory using G0* *. Carry out a conformity check
---------------------	--

<p style="text-align: center;">2</p> 	<p>Bargraph 2 LH, 2 RH, incorrect illumination Fiche n° 27 side 2/2</p> <p><u>THROTTLE POSITION CIRCUIT</u></p> <p>XR25 assistance: BG 2LH illuminated if full load BG 2RH illuminated if no load BG 2LH and BG 2RH extinguished if middle position.</p>
---	---

<p style="text-align: center;">NOTES</p>	<p>No fault bargraph should be illuminated</p>
---	--

The fault is not electrical.
Check the mechanics of the accelerator circuit (cable, accelerator pedal, ...).

<p style="text-align: center;">AFTER REPAIR</p>	<p>Carry out a conformity check</p>
--	-------------------------------------

<div data-bbox="366 248 388 282">3</div> 	<div data-bbox="631 206 1378 257">Bargraph 3 LH, incorrect illumination</div> <div data-bbox="1683 212 2011 251">Fiche n° 27 side 2/2</div> <div data-bbox="631 271 1181 322"><u>FLYWHEEL SIGNAL CIRCUIT</u></div> <div data-bbox="631 333 912 373">XR25 assistance:</div> <div data-bbox="1135 333 1725 373">BG 3LH illuminated engine running</div>
<div data-bbox="303 579 447 624">NOTES</div>	<div data-bbox="631 540 1190 579">Dealt with in the fault bargraphs.</div>

<div data-bbox="227 2647 521 2692">AFTER REPAIR</div>	<div data-bbox="631 2669 720 2709">None</div>
---	---

3

Bargraph 3 RH incorrect illumination
ENGINE IMMOBILISER CIRCUIT

Fiche n° 27 side 2/2

XR25 assistance:

BG 3LH illuminated, engine immobiliser active

NOTES

Check the use of the correct PLIP if no fault bargraph is illuminated.

XR25 as a pulse detector,  and Vin.

Check for pulses on track 37 of the bornier when the PLIP is pressed


If pulses are noted, replace the injection computer.

If no pulses are noted, refer to the immobiliser fault finding section.

AFTER REPAIR

Carry out a conformity check

4

**Bargraph 4 LH incorrect illumination**
PARK/NEUTRAL POSITION CIRCUIT

Fiche n° 27 side 2/2

XR25 assistance:

Illuminated if Park/Neutral position

NOTES

Only with automatic transmission


XR25 on voltmeter  .

Connect a wire to Vin and track 7 of the injection computer.

Ignition on, engage and release the gear lever in the P/N position, the voltage should change from 0 V to 5 V.

If correct, replace the injection computer.

If there is not 0 V / 5 V, check the insulation and continuity of the line:

Injection computer 7  37 Automatic transmission computer

Repair if necessary.

The fault persists! Refer to the automatic transmission fault finding section


AFTER REPAIR

Carry out a conformity check

<div>4</div> <div><div></div><div></div></div>	<div>Bargraph 4 RH incorrect illumination<div>Fiche n° 27 side 2/2</div></div> <div><u>+ AFTER IGNITION CIRCUIT</u></div> <div>XR25 assistance: BG 4RH illuminated if \rightarrow after ignition</div>
--	---

<div>NOTES</div>	<div>Dealt with in the fault bargraphs.</div>
------------------	---


<div>AFTER REPAIR</div>	<div>None</div>
-------------------------	-----------------

<div>5</div> <div></div>	<div>Bargraph 5 LH incorrect illuminationFiche n° 27 side 2/2</div> <div><u>TORQUE REDUCTION CIRCUIT</u></div> <div>XR25 assistance:Illuminated every time a gear is changed with automatic transmission</div>
---	---


NOTES	<p>Only with automatic transmission Status bargraph 4 LH is correctly illuminated.</p>
--------------	--

Since status bargraph 4 LH is correctly illuminated, the injection computer is not faulty.
Refer to the automatic transmission fault finding section


AFTER REPAIR	<p>Carry out automatic transmission fault finding if status bargraph 4 LH is correctly illuminated</p>
---------------------	--

<div style="text-align: center;">6</div> 	<div style="text-align: right;">Fiche n° 27 side 2/2</div> <p>Bargraph 6 LH incorrect illumination</p> <p><u>RICHNESS REGULATION CIRCUIT</u></p> <p>XR25 assistance: BG 6LH illuminated when the richness is regulated (Engine running)</p>
--	--

NOTES	Dealt with in the fault bargraphs.
--------------	------------------------------------



<div style="text-align: center;">6</div> 	<div style="text-align: right;">Fiche n° 27 side 2/2</div> <p>Bargraph 6 RH incorrect illumination</p> <p><u>IDLE REGULATION CIRCUIT</u></p> <p>XR25 assistance: BG 6RH illuminated engine running</p>
---	---

NOTES	Dealt with in the fault bargraphs.
--------------	------------------------------------

<div style="text-align: center;">7</div> 	<div style="text-align: right;">Fiche n° 27 side 2/2</div> <p>Bargraph 7 RH incorrect illumination</p> <p><u>CANISTER BLEED CIRCUIT</u></p> <p>XR25 assistance: BG 7RH illuminated when canister bleed authorised.</p>
--	---

NOTES	Dealt with in the fault bargraphs.
--------------	------------------------------------


AFTER REPAIR	
---------------------	--

<p style="text-align: center;">9</p>  <p style="text-align: center;">10</p> 	<p>Bargraphs 9LH, 10LH, 10RH incorrect illumination Fiche n° 27 side 2/2</p> <p><u>AIR CONDITIONING CIRCUIT</u></p> <p>XR25 assistance:</p> <p>9LH illuminated if air conditioning selected 10LH illuminated if air conditioning requested 10RH illuminated if air conditioning authorised</p>
--	--

NOTES	All fault bargraphs must be dealt with, air conditioning must be fitted on the vehicle and selected
--------------	---

<p>Connect the bornier Sus. 1228 instead of the computer and check the insulation and the continuity between track:</p> <p>Injection computer 5 \longrightarrow B4 Air conditioning control panel 51 \longrightarrow B5</p> <p>Repair if necessary.</p>	
<p>XR25 on voltmeter <input type="checkbox"/> V , check on track 5 of the bornier for the presence of 12 V. There is not 12 V, refer to the air conditioning fault finding section.</p>	
<p>XR25 on voltmeter <input type="checkbox"/> V injection computer connected, check for the presence of 12 V on track B5 of the air conditioning control panel.</p>	
<p>There is not 12 V, replace the injection computer.</p>	
<p>There is 12 V, refer to the air conditioning fault finding section.</p>	

AFTER REPAIR	Carry out a conformity check
---------------------	------------------------------

<div>12</div> <div></div>	<div>Bargraph 12 LH incorrect illuminationFiche n° 27 side 2/2</div> <div><u>EGR CONTROL CIRCUIT</u></div> <div>XR25 assistance:BG 12LH illuminated when the EGR is operated (engine running)</div>
NOTES	Dealt with in the fault bargraphs.

AFTER REPAIR	None
---------------------	------

NOTES

Only refer to these customer complaints after having performed a complete test using the XR25.

STARTING PROBLEMS

	Does not start	Chart 1
	Starts but stalls	Chart 2
	Starting is too long	Chart 3

IDLE PROBLEMS

	Too fast	Chart 4
	Too slow	Chart 5
	Engine unstable	Chart 6
	Hunting	Chart 7

BEHAVIOUR WHEN DRIVING

	Lacks performance	Chart 8
	Misfiring and hesitation	Chart 9

SMOKE - POLLUTION

	Gas analysis not correct	Chart 10
	Testing the oxygen sensor	Chart 11

HIGH PETROL CONSUMPTION

Chart 12


ENGINE NOISE

	Pinking	Chart 13
--	---------	----------


Chart 1

STARTING PROBLEMS
Does not start**NOTES**

Only refer to this customer complaint after having performed a complete test using the XR25.

**AFTER REPAIR**

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 1
CONT**AFTER REPAIR**


Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 1A

STARTING PROBLEMS
Does not start

NOTES

Only refer to this customer complaint after having performed a complete test using the XR25.



AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 2**STARTING PROBLEMS**
The engine starts but stalls**NOTES**

Only refer to this customer complaint after having performed a complete test using the XR25.

Ignition on,
on the XR25, check the value of
#12 and 21.
Are these values coherent?

no

Refer to bargraph 14 LH fault chart.

yes

Check the air inlet circuit and the exhaust
pipe.
Repair if necessary.
If the fault persists

Check the fuel flow and pressure.
Repair if necessary [pump, filter, regulator,
pipes, injectors (seals) ...]
If the fault persists

There is a problem with the engine
and the injection is not faulty.

AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 3

STARTING PROBLEMS
Starting is too long**NOTES**

Only refer to this customer complaint after having performed a complete test using the XR25.

Connect the OPTIMA 5800 diagnostic station and perform a starting test. Does the station detect a fault?

yes

Follow the instructions.

no

Perform a test on the station with the engine running.
Does the station detect a fault?

yes

Follow the instructions.

no

Check the fuel flow and pressure
(Refer to vehicle Workshop Repair Manual.
Repair the fuel circuit if necessary (pump,
filter, pipes, regulator, injectors...)).
If the fault persists

Check the injectors are correctly sealed.
If they are not correctly sealed,
replace the faulty injector or injectors.
If the fault persists

There is a problem with the engine and the
injection is not faulty.

AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 4

IDLE PROBLEMS
Idle too fast**NOTES**

Only refer to this customer complaint after having performed a complete test using the XR25.

R > theoretical idle speed or #12 < theoretical value
especially power assisted steering pressostat, #02 (coolant temperature)

Check no air is leaking into the manifold
(seals, take-off points on the inlet manifold,
plugs, ...).
Repair if necessary.
If the fault persists

Check on the throttle body that it is up
against the lower mechanical stop (#17 <
theoretical value). Also check the accelerator
control. Repair if necessary.
If the fault persists

Check the fuel pressure is not too high.
Repair if necessary
(injectors, pump, pressure regulation,
pipes, ...).
If the fault persists

The injection is not faulty.
Check the engine.

AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 5

IDLE PROBLEMS
Idle too slow**NOTES**

Only refer to this customer complaint after having performed a complete test using the XR25.
 $R < \text{theoretical idle speed}$ or $\#12 > \text{theoretical value}$

Connect the OPTIMA 5800 diagnostic station and perform an ignition test with the engine running.

Does the station detect a fault?

yes

Follow the instructions.

no

Check the fuel flow and pressure (refer to vehicle Workshop Repair Manual).
Repair the fuel circuit if necessary (pump, filter, pipes, regulator, injectors, ...).
If the fault persists

The injection is not faulty.
Check the engine.

AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 6

IDLE PROBLEMS
Engine unstable

NOTES

Only refer to this customer complaint after having performed a complete test using the XR25.

Perform a gas analysis
(Refer to fault chart 10 - smoke/pollution).
If the fault persists

Connect the OPTIMA 5800 diagnostic station
and perform an ignition test with the engine
running.
Does the station detect a fault?

yes

Follow the instructions.

no

Check the operation of the oxygen sensor
(Refer to fault chart 11 - smoke/pollution).
If the fault persists

Engine idling, check the coherence of #01
(the value read should be less than 500 mbar).
Is it correct?

no

Check the absolute pressure sensor and its
wiring loom. Repair,
and if necessary replace the sensor.

yes

Check the fuel flow and pressure
(refer to vehicle Workshop Repair Manual).
Repair the fuel circuit if necessary (pump,
filter, pipes, regulator, injector, ...).
If the fault persists

A

AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 6
CONT**A**

Check the seal and the flow of the injectors.
Repair if necessary.
If the fault persists

Check the general condition of the engine
using engine compression tests with the
OPTIMA 5800 station.

AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 7**IDLE PROBLEMS
Hunting****NOTES**

Only refer to this customer complaint after having performed a complete test using the XR25.

Perform a gas analysis
(Refer to fault chart 10 - smoke/pollution)
If the fault persists

Connect the OPTIMA 5800 diagnostic station
and perform an ignition test with the engine
running.
Does the station detect a fault?

yes

Follow the instructions.

no

Check the operation of the oxygen sensor
(Refer to fault chart 11 - smoke/pollution).
If the fault persists

Check there is no air leak on the inlet
manifold and check the operation of the
injectors (seizing...).

AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 8**BEHAVIOUR WHEN DRIVING**
Lacks performance**NOTES**

Only refer to this customer complaint after having performed a complete test using the XR25.

Check the throttle opens fully
(full load bargraph illuminated).
Check the adjustment of the accelerator
control. Repair if necessary.
If the fault persists

Check the air filter: dirty, deformed. Repair if
necessary.
If the fault persists

Connect the OPTIMA 5800 diagnostic station
and perform an ignition test with the engine
running.
Does the station detect a fault?

yes

Follow the instructions.

no

Perform a gas analysis
(Refer to fault chart 10 - Smoke/pollution).
If the fault persists

Connect the OPTIMA 5800 diagnostic station
and perform an engine compression test
Is it normal?

no


There is a problem with the engine.

yes

A

AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 8
CONT**AFTER REPAIR**

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 9

BEHAVIOUR WHEN DRIVING
Misfiring and hesitation

NOTES

Only refer to this customer complaint after having performed a complete test using the XR25.

Perform a road test if possible to highlight the fault.
If the fault is reproduced

Connect the OPTIMA 5800 diagnostic station and perform an ignition test with the engine running.
Does the station detect a fault?

yes

Follow the instructions.

no

Perform a gas analysis
(Refer to fault chart 10 - Smoke/pollution).
If the fault persists

Check the oxygen sensor
(Refer to fault chart 1.1 - Smoke/pollution).
If the fault persists

Check for the presence and the cleanliness of the restriction in the absolute pressure sensor pipe.
Repair if necessary.
If the fault persists

Check the seal of the injections, and the fuel flow and pressure (refer to Workshop Repair Manual). Repair if necessary.
If the fault persists

A

AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 9
CONT**A**

Check the condition of the flywheel target.
This is done by using the engine speed sensor
signal display function on the OPTIMA 5800
station.
Repair if necessary.
If the fault persists

Check the valves are not clogged.
Clean the valves if necessary.
After cleaning, does the fault persist?

yes

There is a problem with the engine,
the injection is not faulty.

AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using GO**
Carry out a conformity check

Chart 10

SMOKE - POLLUTION
Gas analysis not correct
NOTES

Only refer to this customer complaint after having performed a complete test using the XR25.

Connect the OPTIMA 5800 diagnostic station and connect it to a 4040, 5040 or AGM 1500 type 4 gas analyser. Perform an anti-pollution/ gas analysis test. Does the station detect a fault?

no

End of fault finding using fault chart 10
NOTE: a correct gas analysis indicates that the catalytic converter is working correctly.

yes

Is the CO too high (CO > 0.5 when idling or CO > 0.3 at 2500 rpm.) ?

yes

Check the oxygen sensor
(Refer to fault chart 11 - Smoke/pollution).
If the fault persists.

no


Check there is not a problem with the engine
by performing a compression test
(OPTIMA 5800 diagnostic station).

Check the catalytic converter (efficient, fusion, presence of lead, ...), the air supply (filter, manifold, ...), and the condition of the engine (abnormal oil consumption).

A


AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 10
CONT 1**AFTER REPAIR**

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 10 CONT 2



AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 10
CONT 3**A**Is the oxygen level too high ($O_2 > 0.8 \%$)

yes

Connect the OPTIMA 5800 diagnostic station
and perform an ignition test with the engine
running.
If the station does not detect a fault

no

Check there is no air leak on the inlet
manifold and check the operation of the
injectors (seizing...).

CO₂ too low.

yes

Check the sealing of the exhaust pipe after
the catalytic converter and check the
operation of the injectors (seizing...).

AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 11

SMOKE - POLLUTION **Testing the oxygen sensor**

NOTES

Only refer to this customer complaint after having performed a complete test using the XR25, especially the following parameters:

- #35 (richness correction): this should oscillate around 128
- #30 and #31 (adaptive richness): under no circumstances should they be at their limits.

Connect the OPTIMA 5800 diagnostic station and perform an anti-pollution / oxygen sensor test.
Does the station detect a fault?

no

End of fault finding using fault chart 11.
The oxygen sensor is not faulty.

yes

Check the sensor heating:
- presence of ~ 12 V at the connector with the engine running,
- the sensor heating resistor is not in an open circuit or short circuited to earth.
If the heating is correct

Is the minimum voltage too high?
($U_{min} > 300 \text{ mV}$: signal offset towards richness).

yes

Connect the OPTIMA 5800 diagnostic station and perform an ignition test with the engine running.
If the station does not detect a fault

no

Check the fuel pressure (regulator), the injectors (seal,...) the anti-evaporation circuit (canister) and the fuel grade.
Repair if necessary.
If the fault persists

Replace the sensor.


A

AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 11

CONT 1



AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 11
CONT 2

A

Sensor period incorrect (> 1 second).

yes

The sensor may become clogged or polluted (silicon) if the sensor is open for a long time. An additional fault finding operation is possible using a 4 gas analyser (SOURIAU 4040-5040 or SAGEM AGM 1500) since, in this case, $\text{Lambda} > 1.03$ and $\text{O}_2 > 1\%$. Perform a road test to unclog the sensor. Does it open correctly?

no

Replace the sensor.

AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 12

HIGH FUEL CONSUMPTION

NOTES

Only refer to this customer complaint after having performed a complete test using the XR25.

Check there are no fuel leaks.
Repair if necessary.
If the fault persists

Check the idle speed
(#06 on XR25).
Is it correct?

no

Refer to fault chart 4 or 5, idle problems
(idle speed too fast or too slow).

yes

Check the vehicle complies with its definition
and is in good condition.
Repair if necessary.
If the fault persists

Perform a gas analysis
(Refer to fault chart 10 - Smoke/pollution).
If the fault persists

Check the operation of the O₂ sensor
(Refer to fault chart 11 - Smoke/pollution).
If the fault persists

A

AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 12 CONT

A

Connect the OPTIMA 5800 diagnostic station
and perform an engine compression test.
Is it normal?

no

There is a problem with the engine.

yes

Check the petrol flow and pressure
(methods, refer to vehicle Workshop Repair
Manual) and the canister bleed circuit.
Repair if necessary
(regulator, pump, filter, pipes).
Does the fault persist?

yes

This is not an injection problem, there is a
problem with the engine.
Check:

- engine oil level
- coolant
- axle assemblies
- the general condition of the engine.

 If necessary, perform a consumption test with
the ECONOTEST consumption device.

AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 13

ENGINE NOISE
Pinking**NOTES**

Only refer to this customer complaint after having performed a complete test using the XR25.

Perform a road test with the XR25 and check
13, 15.
Is the fault reproduced?

no

The customer must use his vehicle under
specific conditions, check with the customer.

yes

Perform a gas analysis
(Refer to fault chart 10 - Smoke/pollution).
If the fault persists

Check the operation of the O₂ sensor
(Refer to fault chart 11 - Smoke/pollution).
If the fault persists

Ask the customer what type of fuel he uses.
Is it suitable?

no

Remind the customer what type of fuel he
should use.

yes

Check the condition and the conformity of
the spark plugs.
Replace the spark plugs if necessary.
Does the fault persist?

yes

A

AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 13
CONT

A

Check the conformity: of the routing of the
inlet air pipes and the air filter.
Repair if necessary.
Does the fault persist?

yes

Using a stroboscopic light and the XR25, #51,
check the ignition advance
Are the values the same?

no

Refer to bargraph 5 RH fault chart.

yes

This is not an injection problem.
Also check the engine cooling. The
combustion chambers may have to be
cleaned.

AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

NOTES

Only refer to these customer complaints after having performed a complete test using the XR25

STARTING PROBLEMS

	Does not start	Chart 1
	Starts but stalls	Chart 2
	Starting is too long	Chart 3

IDLE PROBLEMS

	Too fast	Chart 4
	Too slow	Chart 5
	Engine unstable	Chart 6
	Hunting	Chart 7

BEHAVIOUR WHEN DRIVING

	Lacks performance	Chart 8
	Misfiring and hesitation	Chart 9

SMOKE - POLLUTION

	CO and/or HC too high	Chart 10
--	-----------------------	----------

HIGH PETROL CONSUMPTION

Chart 11

ENGINE NOISE

	Pinking	Chart 12
--	---------	----------



The method without the OPTIMA station does not comply with a sufficient quality criterion.
Use the method with the OPTIMA station to obtain this quality criterion.

Chart 1

STARTING PROBLEMS
Does not start**NOTES**

Only refer to this customer complaint after having performed a complete test using the XR25

Check the impact sensor is correctly engaged.
Check all the injection fuses
- Passenger compartment connection unit
- Engine connection unit
Repair if necessary. If the fault persists

Does the fuel pump make a noise when the ignition is turned on?

yes

See Chart 1A

no

Perform control mode G10*
and check if the relay makes a noise
(several clicking noises). Is it correct?

no

Replace the relay

yes

Check for the presence of 12 V on track H3
of this relay.
Repair if necessary.
If the fault persists

During the timed phase, check for the
presence of 12 V on track H5 of this relay.
Is it correct?

no


Replace the relay

yes

A

AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 1
CONT**AFTER REPAIR**


Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 1A

STARTING PROBLEMS
Does not start


NOTES

Only refer to this customer complaint after having performed a complete test using the XR25.



AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**

Chart 1A
CONT**AFTER REPAIR**

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**

Chart 2

STARTING PROBLEMS

The engine starts but stalls

NOTES

Only refer to this customer complaint after having performed a complete test using the XR25

Ignition on,
check on the XR25
the value of #12 and 21.
Are these values coherent?

no

Refer to bargraph 14 LH fault chart.

yes

Check the air inlet circuit and the exhaust
pipe.
Repair if necessary.
If the fault persists

Check the petrol flow and pressure.
Repair if necessary [pump, filter, regulator,
pipes, injectors (sealing) ...]
If the fault persists

This is an engine problem
and the injection is not faulty.


AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 3

STARTING PROBLEMS
Starting is too long**NOTES**

Only refer to this customer complaint after having performed a complete test using the XR25

**AFTER REPAIR**

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 4**IDLE PROBLEMS****Idle too fast****NOTES**

Only refer to this customer complaint after having performed a complete test using the XR25.

$R > \text{theoretical value}$ or $\#12 < \text{theoretical value}$

Check there is no air leak on the inlet (seals, take-off points on the inlet manifold, plugs, ...).

Repair if necessary.

If the fault persists

Check on the throttle body that it is up against the lower mechanical stop ($\#17 < \text{theoretical value}$). Also check the accelerator control.

Repair if necessary.

If the fault persists

Check the fuel pressure is not too high.

Repair if necessary

(injectors, pump, pressure regulator, pipes, ...).

If the fault persists

The injection is not faulty.

Check the engine.

AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected

Erase the computer memory using G0**

Carry out a conformity check

Chart 5

IDLE PROBLEMS
Idle too slow**NOTES**

Only refer to this customer complaint after having performed a complete test using the XR25
 $R < \text{theoretical value}$ or $\#12 > \text{theoretical value}$

Check the ignition, high voltage leads, spark plugs and power stages.
Repair if necessary.
If the fault persists



Check the fuel pressure is not too low.
Repair if necessary
(injectors, pump, regulator, pipes, ...).
If the fault persists



The injection is not faulty.
Check the engine.

AFTER REPAIR


Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 6

IDLE PROBLEMS
Engine unstable


NOTES

Only refer to this customer complaint after having performed a complete test using the XR25



AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using GO**
Carry out a conformity check

Chart 6
CONT**AFTER REPAIR**

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 7

IDLE PROBLEMS
Hunting**NOTES**

Only refer to this customer complaint after having performed a complete test using the XR25

Check the value of the pollutants and Lambda.

- CO < 0.3 %
 - HC ≤ 100 ppm
 - CO₂ ≥ 14.5 %
 - 0.97 ≤ Lambda ≤ 1.03
- Is it correct?

no

Check:

- the catalytic converter (melted, blocked, ...).
- the oxygen sensor (polluted, heating faulty, ...).
- air leak upstream of the oxygen sensor.
- the seal of the exhaust pipe.
- the type of fuel used.
- the ignition (spark plugs, high voltage leads, coils).
- the general condition of the engine (timing, ...).

yes

Disconnect the oxygen sensor and wait for #35 to stabilise at 128 and #05 = 0.402, and for bargraph 3 RH to illuminate.
Is the engine stable ?

no

Check there is no air leak on the inlet manifold (plugs, seals, take-off points,...)
Repair if necessary.

yes

Replace the oxygen sensor.

AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 8

BEHAVIOUR WHEN DRIVING
Lacks performance**NOTES**

Only refer to this customer complaint after having performed a complete test using the XR25

Check the throttle opens fully
(full load bargraph illuminated).
Check the adjustment of the accelerator
control.
Repair if necessary.
If the fault persists

Check the conformity of the spark plugs and
their condition.
Repair if necessary.
If the fault persists

Check the values of the pollutants and Lambda.
- CO < 0.3 %
- HC ≤ 100 ppm
- CO₂ ≥ 14.5 %
- 0.97 ≤ Lambda ≤ 1.03
Is it correct?

no

- Check:
- the catalytic converter (melted, blocked, ...).
 - the oxygen sensor (polluted, heating faulty, ...).
 - air leak upstream of the oxygen sensor.
 - the seal of the exhaust pipe.
 - the type of fuel used.
 - the ignition (spark plugs, high voltage leads, coils).
 - the general condition of the engine (timing, ...).


yes

Check the air inlet circuit (air filter,...) and the
exhaust pipe.
Repair if necessary.
Does the fault persist?

A

AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 8
CONT**AFTER REPAIR**


Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 9

BEHAVIOUR WHEN DRIVING
Misfiring and hesitation

NOTES

Only refer to this customer complaint after having performed a complete test using the XR25



AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 9 CONT

A

Disconnect the oxygen sensor and wait for
#35 to stabilise at 128 and #05 = 0.402, and
for bargraph 3 RH to illuminate.
Perform a road test.
Does the fault persist?

no

Replace the oxygen sensor.

yes

Check the condition of the flywheel target.
Repair if necessary.
If the fault persists

Check the petrol flow and pressure
(methods, refer to vehicle Workshop Repair
Manual).
Replace the faulty parts (fuel pump,
regulator, filter, pipes ...).
If the fault persists

Clean the injectors
If the fault persists

Check the valves are not clogged.
Clean the valves if necessary.
After cleaning, does the fault persist?

no

End of fault finding.

yes

This is an engine problem,
the injection is not faulty.


AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using GO**
Carry out a conformity check

Chart 10


SMOKE - POLLUTION
CO and/or HC too high**NOTES**

Only refer to this customer complaint after having performed a complete test using the XR25. CO and / or HC too high
CO > 0.3 % - HC > 100 ppm

**AFTER REPAIR**

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 10 CONT



AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 11

HIGH PETROL CONSUMPTION

NOTES

Only refer to this customer complaint after having performed a complete test using the XR25

Check there are no fuel leaks.
Repair if necessary.
If the fault persists

Check the idle speed
(# 06 on the XR25).
Is it correct?

no

Refer to fault chart 4 or 5, idle problems
(Idle speed too fast or too slow).

yes

Check the vehicle complies with its definition
and is in good condition.
Repair if necessary.
If the fault persists

Check the value of the pollutants and
Lambda.

- CO < 0.3 %
 - HC ≤ 100 ppm
 - CO2 ≥ 14.5 %
 - 0.97 ≤ Lambda ≤ 1.03
- Is it correct?

no

- Check:
- the catalytic converter (melted, blocked, ...).
 - the oxygen sensor (polluted, heating faulty, ...).
 - air leak upstream of the oxygen sensor.
 - the seal of the exhaust pipe.
 - the type of fuel used.
 - the ignition (spark plugs, high voltage leads, coils).
 - the general condition of the engine (timing, ...).

yes

A

AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 11
CONT**A**

Check the petrol flow and pressure
(methods, refer to vehicle Workshop Repair
Manual) and the canister bleed circuit.
Repair if necessary
(regulator, pump, filter, pipes).
If the fault persists

This is not an injection problem,
this is an engine problem,
check :
- the engine oil level
- engine cooling
- axle assemblies
- the general condition of the
engine.
If necessary, perform a consumption test with
the ECONOTEST consumption device.


AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 12

ENGINE NOISE
Pinking**NOTES**

Only refer to this customer complaint after having performed a complete test using the XR25

**AFTER REPAIR**

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check

Chart 12
CONT

A

Check the conformity of the routing of the inlet air pipes.
Repair if necessary.
If the fault persists

Using a stroboscopic light and the XR25, #51,
check the ignition advance
Are the values the same?

no

Refer to bargraph 5 RH fault chart.

yes



This is not an injection problem.
Also check the engine cooling. The
combustion chambers may have to be
cleaned.

AFTER REPAIR

Check the sensors disconnected during the operation are correctly reconnected
Erase the computer memory using G0**
Carry out a conformity check








NOTES

Engine cold, ignition on

Order of operations	Function to be checked	Action	Bargraph	Display and Notes
1	Dialogue with XR25	D13 (selector on S8)		9.NJ Use fiche n° 27 fault test side
2	Interpretation of normally illuminated bargraphs		<div>1</div>  <div>1</div> 	Fault test Code present
3	Conformity of computer	G70*		X X X X Part Number number displayed in three sequences (refer to section 12)
4	Switching to status test	G01*		10.NJ Use fiche n° 27 status test side

NOTES

Engine cold, ignition on

Order of operations	Function to be checked	Action	Bargraph	Display and Notes
5	Interpretation of normally illuminated bargraphs		1 	Code present
			2 	No load recognition
			4 	Receiving + after ignition information
			4 	Illuminated for automatic transmission, Park or Neutral positions
6	Throttle position potentiometer	No load # 17	2 	$5 < X < 47$
		Accelerator pedal lightly pressed	2 	
		Full load # 17	2 	$164 < X < 253$


NOTES

Engine cold, ignition on

Order of operations	Function to be checked	Action	Bargraph	Display and Notes
7	Absolute pressure sensor	# 01		X = local atmospheric pressure
8	Coolant temperature sensor	# 02		X = ambient temperature $\pm 5^{\circ}\text{C}$
9	Air temperature sensor	# 03		X = ambient temperature $\pm 5^{\circ}\text{C}$
10	Idle regulation solenoid valve	# 12		The value is variable depending on coolant temperature
11	Engine speed	# 06		X = 0 rpm.
12	Canister bleed	# 23		X = 0.7 %









NOTES

Engine warm, at idle speed after the fan unit has operated at least once (air conditioning and heated windscreen not selected, automatic transmission in Park or Neutral position)

Order of operations	Function to be checked	Action	Bargraph	Display and Notes
1	Switching to status test	G01*		<div>10.NJ</div> <p>Use fiche n° 27 status test side</p>
2	No fault		<div>20</div> 	<p>Check this bargraph is not flashing; otherwise type G02* and turn the fiche over. Repair the faulty component then erase the fault memory (G0**) and return to status test (G01*)</p>
3	Battery voltage	# 04		13 volts < X < 14.5 volts






NOTES

Engine warm, at idle speed after the fan unit has operated at least once (air conditioning and heated windscreen not selected, automatic transmission in Park or Neutral position)

Order of operations	Function to be checked	Action	Bargraph	Display and Notes
4	Interpretation of normally illuminated bargraphs	—	1 	Code present
			2 	No load recognition
			3 	Receiving engine speed information
			4 	Receiving + after ignition information
			4 	Illuminated in Park or Neutral position
			6 	Idle regulation active
			6 	Richness regulation active
			7 	Fuel pump active






NOTES

Engine warm, at idle speed after the fan unit has operated at least once (air conditioning and heated windscreen not selected, automatic transmission in Park or Neutral position)

Order of operations	Function to be checked	Action	Bargraph	Display and Notes
5	Idle speed	Without air conditioning # 06 # 12 Air conditioning selected # 06 Heated windscreen selected. Air conditioning not selected # 06	<div>6</div>  <div>9</div>  <div>10</div>  <div>8</div>  <div>9</div> 	<p> $X = 720 \pm 50 \text{ rpm.}$ (K7M 702-720) $X = 750 \pm 50 \text{ rpm.}$ in P and N (K7M 703) </p> <p> $6 \% < X < 15 \%$ (K7M 702 / 703 in N and P) $10 \% < X < 20 \%$ (K7M 703 in D) $4 \% < X < 14 \%$ (K7M 720) </p> <p>Illuminated depending on the status of the air conditioning</p> <p>$X = 850 \pm 50 \text{ rpm.}$</p> <p>If coolant temperature $> 60^{\circ}\text{C}$ then $X = \text{Basic speed}$ (see above)</p> <p>If coolant temperature $< 60^{\circ}\text{C}$ then $X = 850 \pm 50 \text{ rpm.}$</p>
6	Anti-pinking noise measurement	# 13 (3500 rpm no load)		X variable and not zero




NOTES

Engine warm, at idle speed after the fan unit has operated at least once (air conditioning and heated windscreen not selected, automatic transmission in Park or Neutral position)

Order of operations	Function to be checked	Action	Bargraph	Display and Notes
7	Manifold pressure	# 01 without consumer		X is variable and is around 330 ± 50 mbars (this pressure varies as a function of the altitude)
8	Richness regulation	With stable engine speed of 2500 rpm, then at idle speed # 05 # 35	<div>6</div>  <div>6</div> 	<p>X varies in a range of 50 to 900 mV approximately</p> <p>X is around and varies slightly about 128 with a maximum of 255 and a minimum of 0</p>
9	Adaptive idle correction	# 21		$- 2.4 \% < X < 6.2 \%$ (average value after erasing memory: 0)
10	Canister bleed	# 23	<div>7</div> 	Canister bleed is forbidden. The solenoid valve remains closed $X = 0.7 \%$
11	EGR	# 24	<div>12</div> 	$X = 1.9$
12	Power assisted steering pressostat	# 06	<div>13</div> 	$X = 820$ rpm


NOTES

Test to be performed during a road test

Order of operations	Function to be checked	Action	Bargraph	Display and Notes
1	Switching to status test	G01*		<div>10.NJ</div> Use fiche n° 27 status test side
2	No fault		<div>20</div> 	Check this bargraph is not flashing; otherwise type G02* and turn the fiche over. . Repair the faulty component then erase the fault memory (G0**) and return to status test (G01*)
3	Canister bleed	# 23	<div>7</div> 	Canister bleed is authorised X = variable
4	Vehicle speed information	# 18		X = vehicle speed read on the speedometer
5	Pinking sensor	Vehicle loaded and engine speed of 2000 rpm. # 13 # 15		X = variable and not zero $0 \leq X \leq 6$ (if the sensor is faulty, the advance is systematically retarded by 4° which is not visible on # 15)
6	EGR	# 24	<div>12</div> 	X = variable

NOTES

Test to be performed during a road test

Order of operations	Function to be checked	Action	Bargraph	Display and Notes
7	Adaptive richness	After programming phase # 30 # 31		$0 \leq X \leq 208$ (average value after erasing memory: 128) $104 \leq X \leq 255$ (K7M 702-703) $100 \leq X \leq 255$ (K7M 720) (average value after erasing memory: 128)
8	Torque reduction (Automatic transmission)		5 	Illuminated when gear is changed if speed is greater than 6 mph (10 km/h)

SPECIAL TOOLING REQUIRED

OPTIMA 5800 diagnostic station

CHECKING THE IGNITION USING THE DIAGNOSTIC STATION

The OPTIMA 5800 diagnostic station allows the ignition to be checked in two ways:

- **STARTING TEST:** If the vehicle does not start. When no fault finding operations can be performed with the XR25, this operation checks for the presence and the quality of the ignition under the action of the starter motor.
- **TEST WITH ENGINE RUNNING:** These measurements are in addition to those from the XR25 for customer complaints such as: hesitation, misfiring, incorrect gas analysis, unstable idle ...

In addition, the station's measuring module allows static ignition to be checked using two high voltage clamps, where the coils are dual output (when a firing order is given, two sparks are produced simultaneously: one in the cylinder at the combustion phase and the other in the cylinder at the exhaust phase). During the measurements, the two clamps have to be moved from one coil to the other.

Their power is controlled directly by the computer (the amplifier module is integral with the computer): the station is therefore connected directly to the coil inputs.

CONNECTIONS:

- **K7M engine :** Connect to the two coils after removing the connector cover (blue coloured lead on coil n° 1, right hand side).

MEASUREMENTS:

The ignition is characterised by the following values:

Engine running:

- Spark duration.
- Arcing voltage (or ionising voltage).
- Arcing voltage during the exhaust phase (static ignition).

Starting test:

- Ignition feed voltage.
- TDC sensor signal.
- Command signal (MPA).
- Spark duration.
- Arcing voltage (or ionising voltage).
- Arcing voltage during the exhaust phase (static ignition).

The station checks the coherence of the values obtained for each cylinder, and compares the measurements with a database for each engine type.

SPECIAL TOOLING REQUIRED

OPTIMA 5800 diagnostic station

CHECKING THE OXYGEN SENSOR WITH THE DIAGNOSTIC STATION

Obvious faults relating to the oxygen sensor are detected by the XR25:

- Open circuit.
- Short circuit to earth.
- Short circuit to + 12 V.

The diagnostic station allows operating faults to be highlighted which could not be detected with the XR25. The sensor can be checked for the following customer complaints:


- Excess fuel consumption.
- Irregular idle, hunting.
- Hesitation.
- Incorrect gas analysis.

The station performs the check by being connected in parallel to the signal emitted by the oxygen sensor. This sensor is analysed at a stable engine speed (2 500 rpm), when the richness regulation conditions are concurring (engine warm ...).

CONNECTION:

The 3 track connector of the sensor is located on the clutch bellhousing.

During normal operation, the signal is in the form of a sine wave:



The characteristic parameters of this signal are the maximum voltage, the minimum voltage and the period. For all engine types, the correct values are:

- Maximum voltage > 600 mV.
- Minimum voltage < 200 mV.
- Difference (Maximum voltage - minimum voltage) > 500 mV.
- Period < 1 second.

SPECIAL TOOLING REQUIRED

OPTIMA 5800 diagnostic station
4040-5040 or AGM 1500 4 gas analyser

ANALYSING EXHAUST GASES USING THE DIAGNOSTIC STATION

The OPTIMA 5800 diagnostic station connected to an analyser (SOURIAU 4040-5040 or SAGEM AGM 1500) allows the gases to be checked in accordance with the legislation relating to vehicles with catalytic converters. This test is performed at mid-load and at idle speed with the following limits.

Idle speed	2 500 rpm
CO < 0.5 %	CO < 0.3 %
HC < 100 ppm	HC < 100 ppm

Independently to the legislation, other measurements supplied by the analyser fall within certain tolerances:

Idle speed	2 500 rpm
CO ₂ > 13.5 %	CO ₂ > 13.5 %
O ₂ < 0.8 %	O ₂ < 0.8 %
0.97 < Lambda < 1.03	0.97 < Lambda < 1.03

NOTE: Lambda = 1 / Richness

- Lambda > 1 → Lean mixture
- Lambda < 1 → Rich mixture

The condition Lambda = 1 is essential to ensure the catalytic converter functions correctly.

The station causes the following phases:

- Warming up the engine (oil temperature greater than 60°C).
- Holding for one minute at 2 500 rpm. to activate richness regulation and simultaneous gas measurements.
- If the gas analysis at 2 500 rpm is correct, a measurement at idle speed is taken.

If the analysis is deemed to be incorrect by the station, diagnostic messages appear where the priority of the gases is

1) CO 2) Lambda 3) HC 4) O₂ 5) CO₂

NOTE : The report for the whole anti-pollution test can be printed.